

**INSTALLATION
&
OPERATION MANUAL**


Omega Series

Model SMA9807

Model SMA9815

Model SMA9830

Digital PWM Brushless Servo Amplifiers



GLENTTEK

"Solutions for Motion Control"

TABLE OF CONTENTS

TABLE OF CONTENTS	3
OVERVIEW	6
Product Description	7
FULL FEATURE SERVO AMPLIFIER	7
2-PHASE CURRENT MODE SERVO AMPLIFIER.....	7
PULSE FOLLOWER SERVO AMPLIFIER	7
<i>Quadrature</i>	8
<i>Pulse (step) and Direction</i>	8
<i>CW/CCW Pulse mode</i>	8
Features	9
Digital Amp Control Loop Diagram.....	11
Amplifier Setup Software.....	12
MOTIONMAESTRO INSTALLATION	12
MOTIONMAESTRO AMPLIFIER SETUP FEATURES.	13
<i>Opening of communications</i>	13
<i>Model Information</i>	14
<i>Digital I/O setup</i>	15
<i>Amplifier mode setup</i>	15
<i>Motor Parameters</i>	16
<i>Motor Safety</i>	16
<i>Commutation setup</i>	17
<i>Encoders</i>	17
<i>Trajectory Generator</i>	18
<i>Filters</i>	18
<i>Oscilloscope</i>	18
<i>Terminal Window</i>	20
<i>Amplifier Status</i>	20
<i>Control Loop Signals</i>	21
<i>Digital Inputs</i>	21
<i>Faults</i>	21
<i>Warnings</i>	21
<i>Status</i>	22
<i>Control Panel</i>	22
<i>Motor Tuning</i>	22
<i>Saving parameters to non-volatile memory</i>	23
<i>Creating a back up copy of amplifier parameters on disk</i>	23
HARDWARE	24
STATUS DISPLAY	24
CONTROLLER INPUT AND OUTPUT SIGNALS.....	24
<i>Command signal, Analog input</i>	25
<i>Analog output</i>	26
<i>Discrete Input</i>	26
<i>Limits</i>	27
<i>Amplifier hardware inhibit</i>	27
<i>Amplifier reset</i>	27
<i>Amplifier fault output</i>	27
<i>Encoder output</i>	27

<i>External encoder power</i>	27
POWER INPUT AND OUTPUT SIGNALS.....	27
<i>Bus power</i>	28
<i>Motor power</i>	28
PC INTERFACE.....	28
OPTIONAL RELAY I/O.....	29
ENCODER FEEDBACK.....	30
<i>Encoder power, amplifier supplied</i>	30
<i>Encoder channels A, B and Z</i>	30
<i>Hall channels 1, 2 and 3</i>	30
<i>External event fault</i>	30
RESET.....	30
AMPLIFIER/MOTOR INTEGRATION.....	31
EXTERNAL WIRING OF THE AMPLIFIER.....	31
<i>Serial Port</i>	31
<i>Encoder Logic</i>	31
<i>Power</i>	31
APPLYING POWER TO THE LOGIC SECTION.....	31
PARAMETER SETUP.....	32
PHASING THE MOTOR.....	32
APPLYING POWER TO THE MOTOR.....	33
VELOCITY TUNING.....	34
2-PHASE CURRENT MODE OPERATION TUNING PROCEDURE.....	37
APPENDICES.....	38
A SERVO DRIVE CONNECTIONS.....	39
B COMMUNICATION ERROR CODES.....	43
C AMPLIFIER STATUS CODES.....	44
D GLENTEK SMA9800 SERIES AMPLIFIER COMMANDS.....	45
E AMPLIFIER COMMANDS.....	46
F SMA9800 RATINGS AND SPECIFICATIONS.....	47
<i>Power, Input and Output</i>	47
<i>Signal Inputs</i>	47
<i>Digital Inputs</i>	47
<i>Outputs</i>	48
<i>System</i>	48
<i>Notes</i>	48
G MATCHING MOTOR PHASE LEADS TO AMPLIFIER COMMANDS USING HALL SENSORS.....	49
H DETERMINING ENCODER RESOLUTION AND NUMBER OF POLES.....	54
I COMMUTATION TRACK SIGNALS AND PHASE-TO-PHASE BEMF.....	55
J EUROPEAN UNION EMC DIRECTIVES.....	56
<i>Electromagnetic Compatibility Guidelines For Machine Design</i>	56
<i>Declaration of Conformity</i>	62
K AMPLIFIER TERMS AND TECHNOLOGY.....	63
<i>Terms</i>	63
<i>Technology</i>	66
L AMPLIFIER MODEL NUMBERING.....	67
<i>SMA9807 Amplifier Model Numbering</i>	68
<i>SMA9815 Amplifier Model Numbering</i>	71
<i>SMA9830 Amplifier Model Numbering</i>	74
M FACTORY REPAIR & WARRANTY.....	76
N DRAWINGS.....	78
SMA9807-1 <i>Amplifier module</i>	79

SMA9807-1A-1	Stand alone amplifier	80
SMA9807-2A-2	2 axis base plate chassis installation	81
SMA9807-4A-4	4 axis Installation	82
SMA9815-1	Amplifier module	83
SMA9815-1A-1	Stand alone amplifier	85
SMA9815-2A-2	2 axis base plate chassis installation	86
SMA9815-4A-4	4 axis base plate chassis installation	87
SMA9830-1A-1	Amplifier	88

Overview

This manual guides the application engineer through the steps necessary for a successful installation of an application using the Omega series amplifiers. All features of the digital amplifier are explained and all necessary procedures for installation and tuning are covered. The following sections are presented in the order that would make installation easiest for most first time users of the amplifier.

The “Product Description” and “Features” sections contain information for the application engineer to determine if the Omega series amplifiers are appropriate for his application.

Next MotionMaestro® software is introduced. Enough material is given here to familiarize the application engineer with the tools necessary to setup and tune a motor using the Omega series amplifiers.


The hardware section outlines the hardware and connectors necessary to install a Omega series amplifier into an application.

Once these preliminaries are out of the way, the application engineer is brought through a step by step procedure that accomplishes system setup. In System Setup, the steps necessary to bring up and verify a fully functioning amplifier/motor combination is reviewed.

Finally, Tuning is covered where the application engineer can use MotionMaestro® to fine-tune the digital current or velocity loop to meet the specific demands of the application.

Product Description

Glentek's Omega Series Digital PWM Brushless Servo Amplifiers offer the latest in high performance DSP control of both rotary and linear brushless servo motors. With extensive utilization of surface mount technology and special heat transfer techniques, the Omega Series offers one of the world's most powerful products for a given form factor. The Omega Series is comprised of the following models:



Full Feature Servo Amplifier

The Full Feature servo amplifier operates in current (torque) mode or velocity (RPM) mode, accepts a $\pm 10V$ analog input as a command reference and commutates the motor sinusoidally for ultra smooth operation at low speeds. The amplifier utilizes an incremental encoder to derive the velocity signal and to commutate the motor. The absolute commutation angle is usually determined using Hall sensors or encoder Commutation tracks. However, in some cost sensitive applications where slight motor movement is acceptable upon power up, the amplifier can perform a power-on phase finding algorithm which eliminates the need for Hall sensors or Commutation tracks. Special versions are also available that decode Sanyo Denki, Tamagawa and Yaskawa reduced wire encoders.

2-Phase Current Mode Servo Amplifier

The 2-Phase Current Mode servo amplifier accepts two $\pm 10V$ analog inputs as current command references for two of the motor phases. The third phase is derived from the two reference phases. This model amplifier does not use any feedback devices and is used with controllers that provide the commutation.

Pulse Follower Servo Amplifier

The Pulse Follower servo amplifier incorporates all the features of the Full Feature servo amplifier and also accepts two digital pulse inputs as a position command reference. The two pulse inputs are high speed, differential and optically isolated digital inputs which can be configured to decode three pulse types and can be geared up or down (electronic gearing). The motor position and speed are a function of the number of pulses and the rate of the pulses respectively. The following pulse types can be decoded:

Quadrature

Two pulse inputs in quadrature, such as the output of an incremental encoder or an encoder pot determine both command distance and direction. This pulse decoding is useful to slave one motor to another by connecting the master motor's encoder output to the slave motor's pulse inputs.

Pulse (step) and Direction

The first input is a pulse train used to establish the absolute distance and velocity of the command and the second input is a direction signal used to establish the polarity of the command. Many stepper motor controllers provide this pulse type and allows upgrading a stepper motor system to a servo motor system without the need to change controllers.

CW/CCW Pulse mode

The first input is a pulse train to command positive moves and the second input is a pulse train to command negative moves. This pulse type is also generated by some older stepper motor controllers and may be useful in upgrading to a servo motor system.


Features

- **Digital current loops:** Current loop bandwidths up to 3 kHz.
- **Digitally tuned:** All parameters set digitally. No potentiometers to adjust. DSP control for the ultimate in high performance.
- **Silent operation:** 25 kHz PWM standard.
- **Complete isolation:** Complete optical isolation between signal and power stage.
- **Wide operating voltage:** 30-370 VDC for Amplifier modules and 3U plug-In versions. All stand-alone and multi-axis versions can be ordered for operation from either 110-130 VAC or 208-240 VAC (single or 3-phase, 50/60 Hz). **Note:** SMA9807 Stand-Alone is single phase input power only.
- **Direct AC operation:** No transformer required for stand-alone units or multi-axis chassis. The stand-alone units and multi-axis chassis include DC power supply, cooling fans, soft-start circuitry and a regen clamp with dumping resistor.
- **Fault protection:** Short from output to output, short from output to ground, amplifier RMS over current, amplifier under/over voltage, amplifier over temperature, motor over temperature.
- **RS-232 or RS-485/422:** High speed (115.2K baud) serial communication interface for set-up and tuning. RS-485/422 multidrop with up to 31 amplifiers installed.
- **Software configurable:** Glentek's Windows™ based MotionMaestro© software provides ease of set-up and tuning with no previous programming experience required. This software is Windows™ 95/98/2000/XP and NT compatible.
- **Non-volatile memory:** All parameters and positions are stored in non-volatile memory for reliable start up. In addition, up to two different configurations can be stored in the amplifier's non-volatile memory.
- **Dedicated inputs:** +/- position limits, inhibit, fault, motor over temp and reset signal.
- **Dedicated outputs:** Selectable analog monitor signal, fault discrete and divided encoder output.
- **Three basic models:** Covering almost all servo needs, the Omega Series includes a full feature current/velocity amplifier, a 2-phase input current amplifier, and a pulse following amplifier.
- **Encoder output divider:** The encoder input signal can be divided by user selectable integer 1-8 for the encoder output signal.
Note: Non-standard frequency divisors can be ordered on request.
- **Encoder feedback:** Accepts encoder signals up to 4.3 MHz. Special versions are also available that decode Sanyo Denki, Tamagawa and Yaskawa reduced wire encoders.
- **Status indicator:** 7-segment display indicates amplifier status and diagnostics.

- **Sinusoidal commutation:** For the ultimate in efficiency and smooth motion, Commutates from almost any resolution linear or rotary encoder.
- **SMT construction:** Provides ultra compact size, cost competitive package and high reliability.
- **CE compliant:** All servo amplifiers are CE marked.
- **Parametric filtering:** Provides control engineers advanced filtering to eliminate unwanted system mechanical resonance.

Digital Amplifier Control Loop Diagram

Digital Amp Control Loop Diagram



Amplifier Setup Software

MotionMaestro® is Glentek's Windows based application software that was designed to communicate with the Omega series digital amplifier. MotionMaestro® has many dialogs with values shown in engineering units to make it easy to select and setup the features of the amplifier. MotionMaestro® utilizes the standard ASCII command set and protocols. Although it is not necessary to use MotionMaestro®, installation, setup and tuning is made easier through its use.

MotionMaestro® has many features that allow application engineers to easily configure a digital amp to an application. It has a terminal mode that operates at 115k baud transmission rates, an oscilloscope that can be used to monitor amplifier signals and a tuning dialog that can be used to control the motor input. By using the oscilloscope and tuning dialog, one can monitor step response to determine filter parameters for optimal control loop performance.


MotionMaestro® Installation

MotionMaestro® requires Windows95, Windows 98 SE, Windows ME, Windows NT 4.0, Windows 2000 or Windows XP operating system running on a PC with at least one serial port. It is suggested that you have no less than 3 megabytes of application program disk space remaining on the hard drive prior to installation. The MotionMaestro® install disk is setup to utilize Install Shield to simplify installation. There are only a few setup options offered. In general you can press NEXT or YES until installation is complete. When installation is completed, you will find a MotionMaestro® shortcut on the windows Start\Programs menu.

DO NOT RUN MOTIONMAESTRO® UNTIL YOU HAVE READ ALL OF THIS SECTION.

The MotionMaestro® installation program is named Setup.exe. It is found on disk1 of the distribution floppies or in the MotionMaestro® \disk1 directory of the distribution CD.

The installation will create a Glentek folder in the Program Files folder. A MotionMaestro®_X_X folder is created where _X_X matches the version number. You can have multiple versions of MotionMaestro® installed, if you wish, and they will be placed into their own directories.



Demo Mode - For exploring MotionMaestro without an amplifier connected

When MotionMaestro® is directed to establish communications with the amplifier, the amplifier is queried for a model ID and Firmware version. MotionMaestro® will configure itself and select the appropriate configuration files based on the amplifier returned values.

You can run MotionMaestro® without an amplifier attached and inspect the menu options and dialog. To run in demo mode pull down the Commu-


nications menu and select **Demo**. For communicating with an attached amplifier select **open** under the communications menu.

There are extensive help screens under the Help menu. Select Help Topics and you can read about the usage of MotionMaestro® and its features.

MotionMaestro® amplifier setup features.

This section of this manual is an introduction to MotionMaestro's® features that are required for installation and setup of the Omega series amplifiers. Only those features of MotionMaestro® required for defining motor characteristics are covered. This is not meant to be a step by step tutorial. The "System setup" section is intended as a tutorial for motor setup. You may need to refer to this section when setting up a motor. The following features are reviewed here.

1. Opening of communications.
2. Model Information.
3. Digital I/O setup.
4. Mode setup.
5. Commutation setup.
6. Encoder setup.
7. Trajectory Generator
8. Filters
9. Oscilloscope
10. Terminal Window
11. Motor Parameters.
12. Motor Safety.
13. Amplifier Status.
14. Control Panel.
15. Motor Tuning.
16. Saving parameters.
17. Backing up a copy of amplifier parameters.



Open Communications dialog box

Opening of communications


Before MotionMaestro® can be used, communications must be established between the amplifier and the PC that MotionMaestro® is running on. Before opening communications in MotionMaestro®, you must have a serial communications cable wired as described in the hardware section of this manual. This can be a RS-232 or RS-485/422 wiring. You may also need to set the serial port on your computer as described in the system setup section.

Open communications by selecting the "Open" option on MotionMaestro's® main menu tool bar.

Select the COM port that you connected the serial port cable to and en-


sure that a baud rate of 115200 is selected. When you press OK MotionMaestro® will query the amplifier to determine what amplifier model is connected. If communications is established, you should see a screen similar to the following with all green communications status indicators.

When communications cannot be opened, a dialog is presented indicating so. If you cannot open communications please check your cable, PC COM port settings and power to the amplifier.




MotionMaestro's main window

To the right, MotionMaestro's main window is shown where communications are successfully opened and various setup and monitoring screens are activated. These active screens do not necessarily need to remain within MotionMaestro's main window, they may reside anywhere on the Windows desktop.



MotionMaestro's Sever activated windows.



Model Info Box.

Model Information


For informational purposes, you can refer to the Model Info dialog to view the design features and limits of the particular amplifier. To view this dialog, you must select the "Tools" option on MotionMaestro's® main menu tool bar, then select "Model Info".

Here you will be able to view your firmware version and date, amp model number, power board number and logic board number. In addition, MotionMaestro's Model Info dialog window will display amplifier settings. For example, on the left these settings are current balance offsets, current feedback, continuous current and peak current settings. These settings, in addition to the Bus under-voltage and over-voltage settings, are useful informational tools and are required if the user performs his own scaling of amplifier values..


Digital I/O setup

The Digital I/O settings can be used to tailor the amplifier digital signal inputs to the requirements of your application. Failure to properly setup the Digital I/O signals may result in the amplifier powering up in a fault condition. (Or worse yet a reset condition). To view this dialog, select the “Setup” option on MotionMaestro’s® main menu tool bar, then select “Digital IO...”. Digital I/O signals can be active high or active low depending on the applications. The fault condition is a good example. From this window you can modify what state the amplifier considers to be a fault condition, either high or low.

On this window there are two sets of checkboxes, for each signal, Wkg and Amp. Amp displays the current amp setting while Wkg displays the users choice. The amp is automatically updated as the Wkg box changes.



Dialog box for setting amplifier mode.



Dialog box for setting amplifier mode.

Amplifier mode setup

The full featured amplifier can operate in either current or velocity mode. By selecting the “Setup Mode...” item on the “Setup” option menu, you can configure the amplifier to operate in desired mode.

MotionMaestro® uses the Mode setting to determine text and options on many of the dialog display windows. For example, when the Omega series amplifiers are in current mode, parameters on the **Tuning** dialog pertaining to the velocity loop are not available.

Engineering unit scaling used internally by MotionMaestro® is also adjusted to reflect proper units based on mode.

Dialog box for entering motor parameters.

Motor Parameters

Select “Motor Parameters” on the “Setup” menu to activate the Motor Parameters dialog. The Motor Parameters dialog is used to set digital current loop gains. MotionMaestro® will calculate current loop gains based on the values entered. Select “Motor Parameters” on the “Setup” menu to activate this dialog.

Motor Resistance and Inductance are entered as phase to phase values. If these values are not indicated on the motor label, you can determine these values by measuring the resistance or inductance between two motor wires connecting two phases of the motor. Nominal DC bus voltage is the regulated bus voltage, 160 or 320 volts typically. Current loop bandwidth is a measure of the current loops responsiveness. Generally you want this to be as high as possible. A good starting point is 1500 Hz. In order to update the motor parameters in the amplifier, the amp must be disabled. You can do this by

clicking on the “Disable/Enable Amp” button first then the “Send Values To Amp” button. Pressing F1 displays the dialogs help text. After the values are sent to the amp you may test the values by enabling the amp.

Motor Safety

Motor safety is where limits to protect the motor are entered. The “Motor Safety Setup” dialog is available from the “Setup” menu. There are two sets of boxes, one labeled Working, the other Amplifier. Amplifier displays the current amp setting while Working displays the users selection. Here you can setup a maximum current limit, current foldback and low speed Motor safety is where limits to protect the motor are entered. In order to update the motor parameters in the amplifier, the amp must be disabled. You can do this by clicking on the “Disable/Enable Amp” button first then the “Send Values To Amp” button. Pressing F1 displays the dialogs help text. After the values are sent to the amp, you may test the values by enabling the amplifier.

Dialog box for setting up motor safety parameters.

Commutation Setup

The Commutation dialog window allows you to define a motor's commutation characteristics. Here you specify motor commutation parameters, correction and initialization methods, and encoder positioning. In the motor section, most of the boxes are calculations based on your selected motor parameters. Select "Commutation..." on the "Setup" menu to activate the dialog on the right.

For initial setup most of the commutation screen can be ignored. For example, if Hall sensors are utilized they need to be selected under "Init Method". Then, "Hall Edge" needs to be chosen as correction type. Finally, "Number of Poles" and "Lines per Resolution" need to be entered (Rotary). Selecting linear instead of rotary will display parameters that are specific to a linear motor. Edit boxes that are not available are values that are calculated based on other parameters entered. Encoder Scaling and Remainder are automatically calculated based on the motor and encoder values entered. The working column represents modified values that are sent to the amplifier when clicking the "Send Values to Amp" button. In order to update the commutation values, the amp must be disabled. You can do this by clicking on the "Disable/Enable Amp" button. All edit box parameters are described in the help dialog at the bottom of the dialog. You can activate this dialog by clicking on it and then you may scroll up and down through the help dialog with the up or down arrows. Press F1 to view the dialog help text in notepad. After the values are sent to the amplifier you may test the values by enabling the amplifier.

Dialog box for setting up motor commutation.

Encoder Setup Dialog

Encoder

To view the Encoder dialog window, you select the "Setup" option on MotionMaestro's© main menu tool bar, then select "Encoders...". The Encoders dialog allows setup and access to the encoder configuration parameters. Encoder Output Divisor selects the frequency ratio between the encoder output connector and the encoder input. In addition, you may choose the gear and link ratio of an auxiliary encoder.

Trajectory Generator

The Trajectory setup dialog window will allow you to limit the change of velocity or current command. When command is directed away from zero it's "acceleration" or when directed toward zero it's "deceleration". You can view this dialog by selecting the "Setup" option on MotionMaestro's© main menu tool bar, then select "Trajectory Generator...".

Trajectory Setup Dialog

Filters Setup Dialog

Filters

To view the filter dialog window, select the "Setup" option on MotionMaestro's© main menu tool bar, then select "Filters...". At this point, select which of the four filters you would like to view/program. Three of the filters are cascaded filters in the forward loop and one is a filter in the encoder feedback loop. All four filters can be edited and displayed at the same time, but need to be opened one a time.

From these windows, MotionMaestro© allows you to enter values for defined filter equations. These equations were derived using the Tustin transform to convert variables in the frequency domain to coefficients for the digital domain equations. The first step in generating new coefficients is to select the type of filter desired., such as LL1, LP1,CLP1, etc. Once the type of filter is selected, the appropriate input edit boxes will be displayed.

Oscilloscope Setup

The Oscilloscope can either be accessed under the "Tools" option on MotionMaestro's© main menu or via a button on the toolbar.


There is a “setup” window and a “trace display” window for the Oscilloscope. The Oscilloscope setup window provides for setup of the parameters needed to define the signals to be displayed on the Trace Window.

“Scope Attributes” define the X-Y attributes of the Trace display. An example is X-Axis = Time, this sets the units of the X axis to time. The range can be set for both the X and Y Axis, along with the data rate parameters.

“Trace Attributes” alters the data source and turns on/off different traces. You can monitor up to three traces at one time. All traces are color coded on the Oscilloscope Trace screen.

Setup Screen

The Recording Data section is useful for recording test data to a file. The “File” specifies the name of the file that sampled data will be saved to when the record button is activated on the “Trace display” window. By default these files are saved as .csv file type. When .csv is the file type, the files can be viewed with Microsoft EXCEL.



Oscilloscope Display Screen

The Oscilloscope Trace display screen can display up to three active traces on the display. Each trace is color coded and labeled in the key. The sample rate is also displayed for convenience. The screen can be resized for versatility. Depressing the record button will allow you to record a portion of the trace waves. When record is activated a red light will be displayed near the button.

Terminal Window


The Terminal Window can either be accessed under the “Tools” option on MotionMaestro’s® main menu or via a button on the toolbar. The Terminal has direct communication to the amplifier. You can command the amplifier by typing commands to the terminal window. For example, typing BV then the enter key will send the request to read the Bus Voltage in the amplifier. If you wanted to change the Bus Voltage you would type BV200 then press enter. This would change the Bus Voltage to 200. Query command use just the ASCII letters of the command, where set commands use both Letters and a numerical value for an argument. Caution must be used when this window is activated due to the possibility of entering commands which would have undesirable effects.



Terminal Window

Amplifier Status

MotionMaestro® has a variety of status displays that assists the application engineer in setting up amplifier or diagnosing a amplifier setup. Rather than showing all possible status on one dialog, MotionMaestro® has been designed so that only those applicable to the situation at hand can be displayed. These dialogs continuously send queries to the amplifier to determine the amplifiers current status. The size and location of each status display is saved when exiting the display. When returning to the status the last size and position is used in positioning the window. F1 can be pressed to obtain help on the various items or status in the current dialog.




Dialog for observing control loop status

Digital Inputs

This dialog indicates the state of digital inputs coming into the amplifier. Digital inputs are those inputs that can be characterized as being active or inactive. They are typically associated with one of the controller input and output signal pins. See the associated pin in the hardware section for a description of the digital input of interest. Display this dialog by selecting "Status\Inputs\Digital..." or by utilizing MotionMaestro's toolbar.



Status Display Digital inputs.



Amplifier fault status display.

Faults

Faults occur on conditions that make it impossible to operate the amplifier in a safe and stable condition. When a fault condition occurs, the amplifier is disabled. The amplifier must be reset either with the hardware reset switch or with software (Control Panel dialog) or through the external reset pin. Conditions that cause faults are over currents, high or low bus voltages, excessive operating temperatures, and faulty sensors or amplifier hardware. An external fault can be generated by the controller through the /FAULT pin. See the hardware section for additional information on /FAULT. Display this dialog by selecting "Status\Faults" or by utilizing MotionMaestro's toolbar.

Warnings

A warning status indicates that the amplifier is fully operational, but that it is operating in an unusual mode or in a condition that warrants attention. Current fold back is such a condition. Display this dialog by selecting "Status\Warnings..." or by utilizing MotionMaestro's toolbar.




The Warning dialog

Status

All other amplifier conditions that are not a fault or warning are displayed on the Status dialog. This status display is useful for diagnostics, setup or monitoring during operation. Display this dialog by selecting "Status \System Status..." or by utilizing MotionMaestro's toolbar.



The System status display.



The Control Panel display


Control Panel

A properly connected motor can be controlled using the control panel. The control panel displays the amplifiers commanded current or velocity along with the motors actual velocity. From the control panel, you can easily command the motor. The control panel can be accessed through the "Tools" pull down menu or from the control panel icon on the tool bar.

You may set positioning offsets or an exact position by depressing the "Set Position" button. The Option button will allow you to set the maximum and minimum current, velocity, and position.

Motor Tuning

Fine tuning of motor control loop parameters is accomplished with the "Tuning" dialog. This dialog is accessed through the "Servo Tuning" item on the "Setup" menu and is shown below.




Dialog box for tuning the motor.

This dialog has many tools and features for tuning a motor. Real time motor velocity is always available. One can activate the motor with the "Continuous Step Response" button of the Function Generator. Then by viewing the response pattern on the scope you can see if changes to the tuning parameters improve or diminish performance. If in Velocity mode, velocity loop parameters can be altered. The Oscilloscope can query the amplifier down to a period of 4 milliseconds, which is adequate for most tuning requirements. The Tuning section describes in detail how a motor is tuned.

Saving parameters to non-volatile memory

After a motor is configured and tuned to the applications satisfaction, the parameters must be saved to the amplifier's non-volatile memory. Upon power up or reset, the last saved parameters are loaded in the amplifier. The parameters can be saved to non-volatile memory by selecting the "Save to NVM..." option on the setup menu, as illustrated below.



Saving parameters to amplifier non-volatile memory

Creating a back up copy of amplifier parameters on disk

An amplifier's current parameter settings can be saved to disk file that can later be used to configure another amplifier or to restore an amplifier's parameter settings. This is useful in production environments or where an application has several similar motors.

Select "Backup Amp" on the "Tools" menu to backup these parameters. You will be presented with a Windows style "Save File" dialog. Here you can give the file a meaningful name and location to save the file to. Restore backed up files to an amplifier with the "Restore Backup" selection.



Backing up amplifier parameters to a file on disk.

Hardware

This section describes the amplifier connections and how they are used in the typical application. Refer to the specific amplifier's installation drawing in Appendix N. This drawing indicates the location of the pins described below along with the location of the connector they can be found on.

Status Display

A diagnostic LED is provided for determining the general operating condition of the amp. It is a 7-segment LED display. When 5 volts are being supplied to the logic section of the amp, the decimal point is lit.

When Hall sensors are being used and the amp is operating normally, one of the outer six segments is lit. Each of the six outer segments represent one of the six Hall states in a commutation cycle of a motor. A commutation cycle consists of two poles. In an 8-pole motor the LED will cycle through its six outer segments 4 times for one revolution of a rotary motor. When Hall sensors are not being used the display will show a 0, all outer segments of the LED are lit.

When the motors current is clamped, (i.e. held to zero), or the amplifier is in a fault condition, one of the following characters will be displayed as is appropriate to the fault or state.

- S.** (fault) High-Speed Electronic Circuit Breaker (ECB) tripped. (Short)
- L.** (fault) Low speed ECB tripped.
- E.** (fault) Encoder fault detected.
- H.** (fault) Heatsink over temperature.
- h.** (fault) Motor over temperature.
- b.** (fault) Over Voltage fault. (bus)
- ≡** (fault) power on commutation failed. Three horizontal bars.
- =** (fault) invalid Hall state detected. Top and Bottom horizontal bars.
- 1.** (fault) EEPROM checksum failed.
- C.** (status) Clamp condition active. (Inhibit input)
- c.** (status) Clamp condition active. (Fault Input)
- F.** (status) Foldback condition active.
- O.** (status) Normal operation.
- 8.** (status) Amplifier is in reset.

Controller Input and Output Signals


Signals that typically are connected to an external controller are described in this section. These signals include: the primary command signal interface to the amplifier, an encoder output signal, limits, inhibits, analog output, reset and common.

The following is a list and description of the possible controller I/O signals that can be found on an installation drawing. Each amplifier may have these on different types of connectors depending on the model that was ordered. It is important to refer to appendix A and N.

Signal	Description
SIGNAL 1	Command signal analog input 1, differential signal input.
SIGNAL 2	Command signal analog input 2, differential signal input.
ANALOG OUT	User configurable analog output.
+ LIMIT	Inhibits the motor in the plus direction.
- LIMIT	Inhibits the motor in the minus direction.
INHIBIT	Inhibits the motor in both directions.
/FAULT	Active low fault, Output.
RESET IN	Resets latched faults.
ENC + 5 IN	External +5 volts input, encoder power supply
ENCODER A	Encoder A channel Output
ENCODER B	Encoder B channel Output
ENCODER Z	Encoder Z index Output (reference)
+ 15V OUT	15 volt source positive output
- 15V OUT	15 volt source negative output
+ 5V OUT	5 volt source positive output
PULSE	Pulse signal of Pulse & Direction interface, differential signal input.
DIR	Direction signal of Pulse & Direction interface, differential signal input.

Command signal, Analog input

Pins SIGNAL 1(+) and SIGNAL 1(-) are the command input pins. There is a primary and secondary command input. The command input takes a differential analog signal as referenced to the amplifiers' ground. Input voltage is expected to range from -10 volts to +10 volts. The analog signal is converted using a 12 bit ADC. The analog input stage is a difference amplifier with a differential input impedance of 10Kohm. If a single-ended input is desired, then Signal(-) should be connected to Signal common, and the command input should be connected to Signal(+). This will maintain the proper input gain for a +/-10V input range. In this configuration, the single-ended input impedance is 5Kohm. If the signal polarity is incorrect, the signal gain may be inverted in the software setup using MotionMaestro® (e.g. - 50% instead of +50%.)




Command signal analog input design.

Analog output

ANALOG OUT is an user selectable analog output. The output ranges from -10 volts to +10 volts and has 8 bit (256 step) resolution. The following signals can be selected through MotionMaestro® as signals that can be monitored on ANALOG OUT.

Test Voltage	- A user defined constant test voltage.
Command	- ANALOG INPUT scaled, offset and dead band adjusted.
Absolute Current	- The absolute current that is being delivered by the amplifier.
Encoder Velocity	- A raw velocity, proportional to encoder counts per servo interrupt.
Velocity	- Velocity scaled as Command, Encoder Velocity * Tach gain.
Commanded Current	- Current command to the amplifier.
R Phase	- Current command to the R phase of the motor.
S Phase	- Current command to the S phase of the motor.

The analog output can be used to monitor amplifier signals at the servo update frequency. By doing so, the application engineer can determine the amplifiers true response to commanded signals. The analog output is for reference use only. It is not intended for control purposes. At power on, its value is undetermined until the power on reset has completed. During some amplifier functions, this output is temporarily disabled. These functions include saving and recalling parameters from non-volatile memory. The output is filtered to minimize the switching noise from the PWM amplifier. The analog output is updated once per PWM cycle.



Analog Output design

Discrete Inputs

Limit+, Limit-, Hardware inhibit, and amplifier reset are all single ended discrete inputs using the following circuit.



Limits


The signals LIMIT+ AND LIMIT- can be active low or active high based on a user selected setting, (See Digital I/O Setup). If + LIMIT is activated then positive current through the motor is brought to zero. If - LIMIT is activated then negative current through the motor is brought to zero. These pins are normally high at 5 volts. Although when the current is brought to zero the motor is free to rotate by externally applied forces.

Amplifier Hardware Inhibit

An external discrete input is available for amplifier INHIBIT. When activated the amplifier is disabled. The display indicates C for clamped. The motor is free to rotate via externally applied forces. This pin can be configured as active high or low, (See Digital I/O Setup).

Amplifier reset

The amplifier can be externally commanded to reset with the RESET IN pin. This pin can be configured as active high or low. The amplifier flashes 8, all seven segments lit, while in reset.



Amplifier fault Output

An external discrete fault output is available. This is normally a high signal. A fault condition triggers the output transistor presenting a low signal. If a fault condition is sensed within the amplifier, a low signal will be presented. The following circuit is used.

Encoder output

The encoder out signals are differential output signals. The Encoder output pins are a buffered, divided down representation of the motor encoder. The motor's encoder can be divided by 1-8. Dividing the encoder output by 1, 2, 4, 8, 16, 32, 64 or 128 can be configured as an option. Encoder channels A, B and Z are available as pins ENCODER A+, ENCODER A-, ENCODER B+, ENCODER B-, ENCODER Z+ and ENCODER Z-.

External encoder power

To work reliably, some encoders require more current and/or a higher voltage than can be supplied by the amplifier. An external 5 or 12 volt source can be connected to the ENC + 5 IN pin. This power will be supplied to the encoder at the +V pin (see Encoder Feedback).

Power Input and Output Signals

The signal names for power are listed below:

Pin Name	Description
-----	-----
B-	Input - Negative side of DC buss voltage.
B+	Input - Positive side of DC buss voltage.
PHASE T	Output - Motor phase T.
PHASE S	Output - Motor phase S.
PHASE R	Output - Motor phase R.

Bus power

DC bus power is received at pins B- and B+. DC bus power is used for both the logic and current section of the amplifier. It accepts 70VDC up to 340VDC on the B-/B+ terminals.

Motor power

Motor power is delivered at pins PHASE T, S and R. The motor power is Pulse width Modulated signals used to drive the motor.

NOTE: It is best not to connect the motor power pins until it is established that the logic section is working and operational. This means that with the DC bus pins connected, one should be able to communicate with the amplifier via a serial cable and the motor encoder and Hall sensors should be func-

tioning properly. This can all be determined without connecting the motor power.

PC Interface

The PC interface can be found at the HOST connector. An RS-232 (or optional RS-485/422) interface is on the external of the amplifier. This port is the primary means of communication with the amplifier for setup and control. The port utilizes a DB-9 (or optional RJ45) type connector.

The HOST port, when configured as RS232 (independent of the connector type), is more reliable when a three wire cable is used. For a DB-9 connector, wire only, DB-9 pins 2,3 and 5 straight through. A null-modem will not work. Using a fully wired DB-9 may cause some computers communications problems due to the unused wires acting as an antenna on computer input pins which are not properly terminated.


For the amplifier with an RJ45 connector, the serial cable can be made or purchased for communicating with a PC by configuring a cable with one end being a male RJ45 plug and the other end being a DB9 female connector. The pin-out names are below. Remember that there is no standard for an RS-

485 connector.

<u>DB-9 female</u> <u>Pin - Description</u>	<u>Glentek Amplifier</u> <u>DB-9</u>
1 - Data Carrier Detect	RX- (RS485)
2 - Received Data	TX232/CLK-
3 - Transmitted Data	RX232/RFS-
4 - Data Terminal Ready	n/c
5 - Signal Common	GND
6 - Data Set Ready	RX+ (RS485)
7 - Request to Send	n/c
8 - Clear to Send	TX+ (RS485)
9 - Ring Indicator	TX- (RS485)

The pin-out for the RJ/45 connector on the amplifier is shown below. A cable wired to a DB-9 connector, as shown below, will work with most RS-232 connections. RS-485 wiring depends on the pin-out of the RS-485 card communicating with the amplifier.

<u>DB-9 pins</u> <u>Female</u>	<u>RJ/45 pins</u> <u>Male</u>	<u>AMP</u> <u>Pin description</u>
6 <-----> 1		485 RX+
1 <-----> 2		485 RX -
4 <-----> 3		n/c
5 <-----> 4 *		GND
2 <-----> 5 *		232 TX
3 <-----> 6 *		232 RX
8 <-----> 7		485 TX+
9 <-----> 8		485 TX-
....7		n/c



Female RJ45 pin-out

Note: RS-232 requires connecting only the 3 pins marked with an asterisk above.

Optional Relay I/O

This 5 pin connector provides an interface for relay M1 and M2. Both relays are optional and not part of the standard product. Below the pins are described.

<u>Pin Name</u>	<u>Description</u>
M1+	Relay 1 M function positive side
M1 -	Relay 1 M function common
N/C	No Connection
M2+	Relay 2 M function positive side
M2-	Relay 2 M function common

Encoder Feedback

The following pin description defines the main encoder input port.

<u>Signal</u>	<u>Description</u>
+5V	Amplifier supplied 5 volt source (output)
ENCODER A	Encoder A channel input
ENCODER B	Encoder B channel input
ENCODER Z	Encoder Z channel input
HALL 1	Hall sensor 1 input
HALL 2	Hall sensor 2 input
HALL 3	Hall sensor 3 input
MTR TEMP	Motor over temperature switch input

Encoder power, amplifier supplied

The amplifier can supply 5 volts of encoder power. It is accessible at the +5V pin. The source is rated at 150ma.

Encoder channels A, B and Z

The encoder input uses a 3-stage filter in determining if encoder inputs have changed. An encoder edge is considered valid if it holds a single state for three full encoder clock cycles. An encoder clock cycle is 1/26MHz. If an encoder clock is running at a perfect 50% duty cycle, then the shortest possible edge time is 1/26MHz. Since the signal must pass through the 3-stage filter, the **minimum edge time** for an encoder signal is 3/26MHz or 115ns. This is equivalent to a single channel signal frequency of 8.67Mhz/2 (there are two edges in an encoder signal) or 4.33Mhz. Since encoder signals are not perfectly square or perfectly at a 50 percent duty cycle, the maximum encoder frequency will be somewhat below this.

If the Z channel on the encoder is being utilized, and the Z channel signal width is equal to $\frac{1}{2}$ or a full quadrature pulse, then this signal rate is not affected. If the Z pulse is a quarter of a full quadrature pulse then the minimum edge time is increased to 231ns.

The Z channel is edge sensitive such that swapping Z and Z* does not change the behavior of the amplifier.

Hall channels 1, 2 and 3

26LV32 or equivalent RS422 line receiver inputs. Compatible with differential or single-ended commutation tracks or Hall sensors. Single-ended connections should be made to the "+" input while leaving the "-" input unconnected.

Power-on phase-finding routines available for operation without commutation tracks or Hall sensors.

External event fault

The amplifier can be faulted on an external event with the MTR TEMP pin. This pin can be configured as active high or low. The amplifier displays lower case h when this signal is active, latches the fault and disables the amplifier.

Reset

This switch performs a reset. A reset clears all faults, resets the DSP and initializes the amplifier.

Amplifier/Motor Integration

This section outlines how to connect an amplifier to a motor and how to ensure that the amplifier is correctly connected to the motor. This section is written with the concept of using MotionMastro as the user interface. Having completed the amplifier/motor integration the motor is ready to be tuned for the application.

External wiring of the amplifier.

Serial Port

Purchase or manufacture a serial cable as described above under the description for PC Interface. Connect the female DB-9 connector to the PC that has your terminal software installed. Place the other end of the cable into the HOST port of the amplifier. The default serial settings for this amp are:

Baud rate:	115200
Data bits:	8
Stop bits:	1
Parity:	None

There is no settable software protocol. Set your PC to raw ASCII.

Encoder

Manufacture an encoder cable that will be connected to the encoder feedback port. Use the pin out description under Encoder Feedback above and the installation drawing as a guide.

For the encoder, wire differential channels A, B and Z to the matching amplifier pins. Wire the encoder +5 volt to pin +V. Wire the encoder ground to a COMMON pin.

Hall sensor wires should be wired to their matching amplifier pins HALL 1+, HALL 2+ and HALL 3+. A rotation of the motor should activate Hall 1, 2 and 3 sequentially. Ensure that 5 volts and ground are provided to the Hall sensors through either an external 5 Volts or from the amplifiers +5V pin. If encoder power is supplied from amplifiers +5V pin, make sure that the encoder's current draw is less than the current rating of the +5V pin.

IMPORTANT: Use proper shielding for the encoder logic cable. Tie amplifier common to encoder ground and cable shield. **DO NOT** tie cable shield or encoder ground to motor case.

Power

Testing of the logic section requires that only the bus power terminals B+ and B- be connected. Connect an appropriate DC bus voltage, see Ratings and Specifications, to these pins.

DO NOT CONNECT THE MOTOR POWER CABLE.

Applying Power to the Logic Section

Turn on the DC bus voltage connected to the amplifier. A lit decimal point on the LED display indicates that 5 volts are being supplied to the logic section of the amplifier.

Execute the communications software that is on your PC. Open a terminal window and press Enter on the keyboard. If the amplifier is communicating properly with the PC, the amplifier will respond with a

">" prompt. Each pressing of Enter will result with this prompt.

Parameter Setup

Start MotionMaestro®, establish communications with the amplifier, and enter the "Setup\Select Mode" dialog. Ensure that the amplifier is configured for current mode. **Motor/amplifier checkout is done in current mode.** After checkout is completed you may change to velocity mode if desired.

Enter the "Setup\Commutation" dialog. Configure the amplifiers commutation characteristics as indicated on the dialog. For rotary motors enter the lines per revolution, not encoder counts. This should be found on the encoder nameplate (if lines per revolution and number of poles are not documented for the motor (See appendix "Determining Encoder Resolution and Number of Poles"). This number will need to be derived if linear scales are used. Disable the amp, if it is not already, and send the parameters to the amplifier. Select an appropriate commutation initialization method. (See "Selection of a commutation initialization method" in appendix "Amplifier Terms and Technology").

NOTE: When any parameter that controls commutation is changed it is necessary to re-commutate the motor. This very often is best achieved by executing RST from a terminal window or clicking the Fault Reset button on the control panel.

NOTE: If you are using Hall sensors to maintain commutation, you may want to fine tune your commutation. Hall sensors are typically not perfectly aligned with the amp. Set the Commutation Angle Offset to an appropriate value in MotionMaestro's® "Setup\Commutation" dialog.

Enter the "Setup\Motor Parameters" dialog. (This dialog is not available if your amplifier has an analog current loop). Enter the motor resistance, inductance, the bus voltage and the current loop frequency appropriate to the application.

Disable the amplifier and send the parameters to the amplifier.

Enter the "Setup\Motor Safety" dialog. Set the Current limit to the rated limit of the motor or the rated limit of the amplifier, whichever is smaller. Set the fold back threshold to a value under the current limit. How much the threshold is set under the current limit depends on the dynamics of your application. Start with a value 5 percent under the current limit. If you are not using current fold back then set the fold back threshold to a value above or equal to the current limit. Set the Electronic Circuit Breaker (ECB) values. The low speed ECB protects the motor and amplifier from conditions when the current remains at the current limit for excessive periods of time. Set the LS/ECB threshold to the maximum continuous current of the motor or amplifier, whichever is less. Start with a 2 to 4 second filter time.

Disable the amplifier and send the parameters to the amplifier.

At this point you may want to save the parameters in non-volatile memory. Select "Setup\Save to NVM" from the menu bar.

You may also choose to save the current parameters in the amplifier by saving them to hard disk. Select "Tools\Backup Card" from the menu bar.

Phasing the Motor

If you are matching a motor to the amplifier and you have not received a motor with your amplifier from Glentek, then perform Appendix G ("Matching motor phase leads to amplifier commands using Hall sensors").

Parameter Check

Start MotionMaestro®, establish communications with the amplifier, and enter the Setup\Servo Tuning dialog.

Set the loop gain to zero.

Set the signal gain to zero.

You are now ready to safely apply power to the motor in preparation for tuning.

Applying Power to the Motor

Turn the DC bus power off and wait for the bus to discharge. Connect the motor power leads phase R, S, and T (or phase A, B and C) to the amplifier. Be careful to follow the manufacturers phasing sequence when connecting these leads. Ensure that the motor ground is properly grounded to the amplifier's chassis ground.

NOTE: Turning power on may move the motor, do not have the motor shaft connected to the machine at this time.

Turn the DC bus power on.

Enable the amplifier if it is not already enabled.

From the MotionMaestro® Servo Tuning dialog, slowly increment the loop gain. First 1 percent. If the motor does not “run away” or “lockup” (i.e. hum), then the motor wiring is probably correct. If all appears to be ok, continue increasing the loop gain up to 100 percent.

Open the control panel.

Slowly increase the commanded current in the positive (+) direction until the motor moves. Note the velocity. It should also be positive. If it is not, then check, or uncheck, the Tach Reverse checkbox.

Zero the commanded current.

Disable the amplifier and send the parameters to the amplifier.

Save parameters to NVM.

You are now ready for tuning. Before advancing further save these parameters to non-volatile memory.

Velocity Tuning

Tuning is a process where coefficients in the amplifier's internal equations are matched to the application (motor). Glentek amplifiers can be tuned for two modes of operation: **Current mode** and **Velocity mode**. For Glentek's digital amplifiers, MotionMaestro® can be used to assist in tuning the motor amplifier for the best response in your application.

Current mode tuning must be completed before **Velocity** mode tuning. Current mode tuning is accomplished by entering the motor parameters on the **Motor Parameters** set-up dialog. It is very important the values match the values of the application (motor). This includes the bus voltage applied to the amplifier. The proper **Current** mode parameters are internally calculated based on motor parameters and selected bandwidth. To complete current tuning, the amplifier needs to be checked so as a positive current causes a positive **tach** or encoder reading. This verification is done in **Current mode** from the **Control Panel** dialog. For mode selection see Amplifier Mode Setup in the Amplifier Setup software section.

Example of accomplishing the Current tuning verification is as follows:

1. Turn the power on without connecting the motor power leads to the amplifier, and configure the amplifier in current mode by choosing "Current Loop Closed" option under "Modes of Operation". Actually this is done by deselecting all other modes. The current mode is default and can not be deselected.
MotionMaestro®: Setup > Select Mode...
2. Save to NVM.
MotionMaestro®: Setup > Save to NVM...
3. Turn the power off, and connect the motor leads to the amplifier.
 Note: Make sure to connect the motor leads so the motor is phase to the amplifier properly.
 Refer to Appendix G and I for motor phasing.
4. Turn the power back on, and open the "Control Panel" window.
MotionMaestro®: Tools > Control Panel, or Control Panel icon on the tool bar.
5. Press ">>" (positive command) button until "Actual Velocity (RPM)" box displays motor RPM other than 0.
 Note: 1. The "Actual Velocity (RPM)" should show a positive number
 2. If the "Actual Velocity (RPM)" shows a negative number when positive current was commanded, check "Tach Reverse" box.
6. Try the opposite direction by pressing "<<" button until the motor rotates to the other direction.
 Note: The "Current (Amps)" box and "Actual Velocity (RPM)" boxes should indicate the negative numbers.
7. Stop the motor and close the "Control Panel".

Having completed Current tuning, put the amplifier in **Velocity Mode**.

1. Choose "Velocity Loop Closed" option under "Modes of Operation".
MotionMaestro®: Setup > select Mode...
2. The motor should be tight.
 Note: If the motor runs away, turn the power off, or press the emergency button on your system, immediately. Then, repeat steps 1 through 7.
3. Save the configuration to non-volatile memory.
MotionMaestro®: Setup > Save to NVM...

Start velocity tuning

1. Under the SETUP pull down on the main window menu bar select the "Servo Tuning" dialog window, and enter the following values.
MotionMaestro: Setup > Servo Tuning...

- 1.1 Set "Loop Gain" at 100.
 - 1.2 If compensation is selectable set to conservative value. Set "Compensation" at 0 or 1 or if experienced set to desired value.
 2. Next setup a excitation signal needed during velocity tuning. **MotionMaestro**: In the "Function Generator" group of the tuning dialog window Press "Setup" and do the followings.
 - 2.1 "Tuning Setup" dialog window will appear.
 - 2.2. Enter "BaseVelocity (RPM)". 0 RPM.
 - 2.2. Enter "Target Velocity (RPM)". (200 or your selection) Try to keep it under 1000 RPM.
 - 2.3. Enter "Step Duration (secs) (at target time), and "Inter-Step Dwell (secs) (at base time).
 - 2.4. Choose "Step Direction".
 - 2.5. Choose "Test Mode".

Note: If you are not sure of values for function generator, use default settings.

 - 2.5. Select "OK" to close window.
- Your application may require that you use an analog input that is slewed properly by your applications external control. This can be accomplished by creating an alternate function generator. Apply the desired step input voltage from your system controller to the analog inputs of the amplifier.
3. Next the Scope function needs to be setup and started to display the system velocity response. Press the "Display Oscilloscope" button on the Tuning Dialog window to open the "Setup Oscilloscope" dialog window, and do/select the followings.
 - 3.1. Select X-Axis = time
 - 3.2. Enter Data sampling "Actual Rate (mS)" select time equal to or greater than the shown default. The shown default is calculated based o MotionMaestroã activity and could be too high if activity is increased.
 - 3.3. Select under "Data Attributes" "Source dropdown" the "Velocity Measured" option
 - 3.4. Enter " X-Axis Range": oscilloscope sweep speed
 - 3.5. Enter " Y-Axis Range": Sets the Y axis plus and minus maximum values.

Note: The maximum values should be higher than the actual "Target Velocity (RPM)" from step 2.2.

 - 3.6. Press "Done" to display oscilloscope

Note: 1. You can always go back to the "Setup Oscilloscope" window to reset the ranges by clicking "Setup" in the "Oscilloscope" window.


 2. You should see a trace scanning across the scope. If you do not, press "Setup" button, and adjust the scope until a trace is visible.
 4. Go back to the "Tuning Setup" window, and press the "Start (continuous)" button in the function generator group.

Note: Press "OK" when the "Execute Test" pop up window appears.
 5. Slowly increase the "Compensation" until the oscilloscope waveform shows critically damped response or just one hook overshoot.


Note: 1. This should be achieved without the system becoming unstable.

 2. The compensation can be increased or decreased by the up and down arrow keys on the keyboard when the compensation edit box on tuning dialog of MotionMaestro has the focus.


The following illustrations provide a reference for the waveforms on the Oscilloscope. Figure B, a one hook overshoot signal is a practical target to aim for.




A.) Critically Damped Signal.



B.) 1 Hook Overshoot Signal



C.) Under Damped Signal



D.) Over Damped Signal

7. Additional settings:

Note: In most cases, increasing or decreasing compensation value should tune the amplifier to the application. However, if you still cannot achieve the desired performance, work with some gains listed below.

Gain	Default	Response
Integral	600	If the gain is too high, the system may “hunt” (at low frequency). If the gain is too low, the motor may not overcome the friction or load, and could cause static position error in the system.
Proportional	32767	A high gain gives high stiffness but may oscillate. A low gain gives stable system but gives low stiffness.
Derivative	32767	A high gain gives slower step response but may allow higher proportional gain without oscillation. A low gain gives faster step response but may have overshoot or “ringing” response.
Tach (velocity feedback gain)	16384	

Integral, Proportional, and Derivative gains result in a coefficient which is calculated as the value entered over 32767. The compensation term acts as scalar of each coefficient

8. When you are satisfied with the tuning, save the parameters to non-volatile memory.

When tuning is complete you can save the amplifier parameters to an ASCII text file with MotionMaestro's Backup command. You will find this command under the Tools pull-down menu. Select Backup Card. You will be prompted for a file name. The file can later be found under the application directory with a bk file type descriptor. At a later time this file can be used to quickly load default parameters for an application.

2-Phase Current Mode Operation Tuning Procedure

1. Turn the power on without connecting the motor leads to the amplifier. Configure the amplifier for two phase input on current mode dialog window by choosing "2-phase Current Com/Analog In" option under "Modes of Operation".
MotionMaestro: Setup > Select Mode...
2. Save to NVM.
MotionMaestro: Setup > Save to NVM...
3. Turn the power off, and connect the motor leads and 2 signal inputs (signal 1+/-, signal 2+/-, common) to the amplifier.
Note: Make sure to connect the motor leads properly. Refer to Appendix E and F for motor phasing.
4. Turn the power back on and open the "Analog I/O" window.
MotionMaestro: Setup > Analog I/O...
5. With zero value signal on both of the input signals, adjust "Signal Offset" and "Aux Signal Offset" to null the R and S commands.
Note: 1. Use scope to monitor these commands.
MotionMaestro: Tools > Scope..., or Scope icon on the tool bar.
2. On the Scope set up window
For trace 1 Select "R Current Commanded" option from "Source" under "Data Attributes"
For trace 2 Select "S Current Commanded" option for "Aux Signal Offset"
3. Go back to the Analog I/O setup window and adjust the analog offsets to get a zero value on the commanded signal traces. This will null all offsets from the controller and the amplifier.
6. Set "Signal Gain", and "Aux Signal Gain" to the desired Amps/V.
Note: Both gains should be set to the same value.
MotionMaestro: Setup > Analog I/O...
7. Stop the motor and close the "Control Panel".
8. Choose "Velocity Loop Closed" option under "Modes of Operation".
MotionMaestro: Setup > select Mode...
9. The controller connection to the analog inputs can be verified by commanding 1V to each signal input. Use the MotionMaestro Scope to check that the commanded input is as expected.
For Example: If the signal gains are set to 2.5A/V, 1V is commanded to both inputs simultaneously, and the current limit is greater than 5A, then the MotionMaestro Scope should display 2.5A on phase R and S current commands and -5.0A on phase T current command.

Appendices

APPENDIX A

A - Servo Drive Connections

J2/J6 - Servo Drive Motor and Power Connectors





Table A-1 J2 Module Power/Motor Mating Connectors

Description/Type	5-Pin Female Mating Connector
Right angle	Phoenix GMVSTBW 2,5/5-ST-7,62
Inline	Phoenix GMSTB 2,5/5-ST-7,62

Table A-2 J2 Module Power/Motor Designations

Pin#	I/O	Name	Function
1	Input	B	DC Bus
2	Input	B+	DC Bus +
3	Output	T	Motor Phase T
4	Output	S	Motor Phase S
5	Output	R	Motor Phase R

Table A-3 J2 Stand-Alone Motor Power Mating Connectors




Description/Type	3-Pin Female Mating Connector
Right angle	Phoenix GMVSTBW 2,5/3-ST-7,62
Inline	Phoenix GMSTB 2,5/3-ST-7,62

Table A-4 J2 Stand-Alone Motor Power

Designations Pin#	I/O	Name	Function
1	Output	T	Motor Phase T
2	Output	S	Motor Phase S
3	Output	R	Motor Phase R

Table A-5 J6 Stand-Alone AC Power Mating



Connectors Description/Type	4-Pin Female Mating Connector
Right angle	Phoenix GMVSTBW 2,5/4-ST-7,62
Inline	Phoenix GMSTB 2,5/4-ST-7,62

Table A-6 J6 Stand-Alone AC Power

Designations Pin#	I/O	Name	Function
1	Input	AC	AC, single phase/three phase
2	Input	AC	AC, single phase/three phase
3	Input	AC	AC (three phase only)
4	Input	Gnd	Chassis Gnd

J1 - Servo Drive Serial Communications Connector




Table A-7 DB-9 Serial Communications Mating Connectors

Description/Type	9-Pin Male Mating Connector
Sub Miniature D, 9-Pin	Commercial, DB-9


Table A-8 RS-485/422 Communications Designations

Pin#	I/O	Name	Function
1	Input	-RX-	Receive
2		-	Reserved
3		-	Reserved
4		-	No Connection
5	Power	GND	Ground
6	Input	RX+	Receive +
7		-	No Connection
8	Output	TX+	Transmit +
9	Output	TX-	Transmit

Table A-9 RS232 Communications Designations

Pin#	I/O	Name	Function
1	Output	-	No Connection
2		TX	Transmit
3		Input RX	Receive
4		-	No Connection
5	Power	GND	Ground
6		-	Reserved
7		-	No Connection
8		-	Reserved
9		-	Reserved

Table A-10 RJ-45 Serial Communications Mating Connectors




Description/Type	8-Pin Male Mating Connector
Standard Commercial, RJ-45	Commercial, RJ45

Table A-11 RJ-45 Communications Designations

Pin#	I/O	Name	Function
1	Input +	RS-485 RX +	RS-485 Receive +
2	Input -	RS-485 RX -	RS-485 Receive -
3		NC	
4	Input/output	Ground	Ground
5	Output	RS-232 TX	Transmit
6	Input	RS-232 RX	Recieve
7	Output	RS-485 TX +	RS-485 Transmit +
8	Output	RS-485 TX -	RS-485 Transmit -

J3 - Servo Drive Motor Encoder Connector J3 - Encoder Feedback

Table A-12 J3 Encoder Feedback Mating



Connectors Description/Type	20-Pin Male Mating Connector	20-Pin Male Mating Backshell
Mini D Ribbon, 28-30 AWG, Insulation Displacement, Plastic Backshell, Squeeze Latch	AMP 2-175677-2	AMP 176793-2
Mini D Ribbon, 28-30 AWG, Insulation Displacement, Metal Backshell, Squeeze Latch	3M 10120-6000EC	3M 10320-A200-00
Mini D Ribbon, 24-30 AWG, Solder Cup, Plastic Backshell, Squeeze Latch	3M 10120-3000VE	3M 10320-52F0-008

Table A-13 J3 Encoder Feedback

Designations Pin#	I/O	Name	Function
1	Power	Enc Pwr	Encoder +5 VDC Power
2	Power	Enc Com	Encoder Common
3	Power	Hall Pwr	Hall Sensor +5 VDC Power
4	Power	Hall Com	Hall Sensor Common
5	Input	Enc A+	Encoder Channel A+
6	Input	Enc A-	Encoder Channel A- (not)
7	Input	Enc B+	Encoder Channel B+
8	Input	Enc B-	Encoder Channel B-(not)
9	Input	Enc Z+	Encoder Channel Z+
10	Input	Enc Z-	Encoder Channel Z- (not)
11	Input	Hall 1+	Hall Sensor 1+ Signal
12	Input	Hall 1-	Hall Sensor 1- Signal (not)
13	Input	Hall 2+	Hall Sensor 2+ Signal
14	Input	Hall 2-	Hall Sensor 2- Signal (not)
15	Input	Hall 3+	Hall Sensor 3+ Signal
16	Input	Hall 3-	Hall Sensor 3- Signal (not)
17	Input	Mtr Temp SW	MotorTemp Switch Input
18	Input	Mtr Temp Gnd	MotorTemp Switch Common
19	Power	Gnd	Common
20	Power	Gnd	Common

J1 Controller I/O Connectors




Table A-14 J1 I/O Mating Connectors

Description/Type	36-Pin Male Mating Connector	36-Pin Male Mating Backshell
Mini-D Ribbon, 24-30 AWG, Solder cup. Plastic backshell, squeeze latch	3M10136-3000VE	3M10336-52F0-008

Table A-15 J5 I/O Connection Designations

Pin#	I/O	Name	Function
1	Input	Signal 1 +	Analog 1 command signal +
2	Input	Signal 1 -	Analog 1 command signal – (not)
3	Input	Signal 2 +	Analog 2 command signal +
4	Input	Signal 2 -	Analog 2 command signal – (not)
5		NC	No Connection
6	Output	Common	Analog out common
7	Output	Analog Out	Analog out
8	Input	+ Limit	Limit switch +
9	Input	- Limit	Limit switch -
10	Input	Hw inhibit	Hardware inhibit
11	output	Not fault	Fault Not
12	Input	Common	I/O return
13	Input	Reset In	Reset Amp
14	Input	Mtr Temp	Motor temp input
15	Input	Aux/Enc5	Auxiliary/Encoder 5v input
16	Input	Common	I/O return
17	Output	Encoder Z +	Encoder Z + output
18	Output	Encoder Z -	Encoder Z - output
19	Input	Common	I/O return
20	Input	Common	I/O return
21	Input	Common	I/O return
22	Input	Common	I/O return
23	Input	Pulse -	Pulse input -
24	Input	Pulse +	Pulse input -
25	Input	Direction -	Direction input +
26	Input	Direction +	Direction input +
27	Output	- 15v	- 15 volts out
28	Output	+ 15 v	+ 15 volts out
29	Output	Common	V out return
30	Output	Common	V out return
31	Output	+ 5 volt	+ 5 volts out
32	Output	+ 5 volt	+ 5 volts out
33	Output	Encoder A+	Encoder A+ output
34	Output	Encoder A-	Encoder A- output
35	Output	Encoder B+	Encoder B+ output
36	Output	Encoder B-	Encoder B- output

APPENDIX B

B - Communication Error Codes

This appendix contains definitions of error codes read from an amplifier. Errors may be returned in response to a command sent via a serial line. MotionMaestro® displays the following response when the amplifier returns an error.

```
ERROR= nn  
>
```

The following list defines the error associated with each of the error codes nn.

Error #	Definition
.	Power indicator
0	Unknown error
1	Invalid command
2	Checksum error
3	Reserved
4	Invalid command argument
5	Reserved
6	Reserved
7	Reserved
8	Reserved
9	Reserved
10	Reserved
11	Reserved
12	Reserved
13	Reserved
14	Reserved
15	Motor is enabled
16	Inhibit is active
17	Parameter is locked

APPENDIX C

C - Amplifier Status Codes

This appendix contains definitions of status codes displayed at the amplifier.

The following list defines the condition for each of the display values.

Display	Definition
.	Power indicator, Amplifier held in reset
1	EEPROM Fault
8	Reset (Flashing)
b	Bus Over Voltage
C	Clamp Condition Active (Inhibit input)
c	Clamp Condition Active (Fault input)
E	Fault Input
F	Foldback
H	Heatsink Overtemp
h	Motor Overtemp
L	Low Speed Electronic Circuit Breaker
O	Normal Operation
S	High Speed Electronic Circuit Breaker
U	Under Voltage
=	Hall Fault
≡	Commutation Fault

APPENDIX D

D –Glentek SMA98xx Series Amplifier Commands

The Glentek Omega series digital amplifiers are designed with a robust repertoire of commands. These commands are 1 to 3 ASCII characters.

For a full list of the commands contact your Glentek technical representative.

APPENDIX E

E –Glentek SMA98xx Series Command Communications Protocol

The Glentek Omega series digital amplifiers are designed to operate utilizing a standard serial protocols.

For a full description of the protocol contact your Glentek technical representative.

APPENDIX F

F - SMA98XX Ratings and Specifications

This appendix contains specifications for the application engineer which are necessary to utilize the SMA9800 series amplifiers.

Power, Input and Output

Amplifier Model Number	Input power (Buss Voltage B+)	Output Power		Available Packaging Configurations
		RMS	Peak	
SMA9807-1	30-370 VDC	7	14	Module
SMA9807-1A-1 SMA9807-MM*-N*	110-130 VAC or 208-240 VAC	7	14	Stand-Alone and Multi-Axis
SMA9815LP-1	30-370 VDC	10	20	3U Plug-In and Module
SMA9815LP-1A-1 SMA9815LP-MM**-N**	110-130 VAC or 208-240 VAC	10	20	Stand-Alone and Multi-Axis
SMA9815-1	30-370 VDC	15	30	3U Plug-In and Module
SMA9815-1A-1 SMA9815-MM**-N**	110-130 VAC or 208-240 VAC	15	30	Stand-Alone and Multi-Axis
SMA9815HP-1	30-370 VDC	20	40	3U Plug-In and Module
SMA9815HP-1A-1 SMA9815HP-MM**-N**	110-130 VAC or 208-240 VAC	20	40	Stand-Alone and Multi-Axis
SMA9830-1A-1	110-130 VAC or 208-240 VAC	30	60	Stand-Alone

Signal Inputs

Input Source	Maximum Voltage VDC	Minimum Impedance Ohms	Current Gain Amp/Volt
Differential	13	10,000	0 - 5
Single Ended	13	10,000	0 - 5

* Refer to page 68

** Refer to page 71

Digital Inputs

<u>Input Source</u>	<u>Specification</u>
Limit +	See *
Limit -	See *
Inhibit	See *
Reset	See *
Fault (as input)	See *
Motor Temp	See *
*	40V max. -.5V min. Terminated by 10k Ohms. Digital inputs have hysteresis with thresholds at 1/3 and 2/3 of 5V.

Outputs

<u>Output</u>	<u>Specification</u>
Fault (as output)	Active low, open collector output can sink 500 mA max.
Analog Out	User selectable D/A. Output capable of driving 2K ohm load at 5 Volts.
Encoder Outputs:	EIA-422-A differential line driver, 2631 compatible.

System

<u>Feature</u>	<u>Specification</u>
Frequency response	
Velocity Loop:	Implementation dependent.
Current Loop:	Typical, depending on motor inductance, 2kHz typical. (Bandwidths available up to 3 kHz.)
Dead band:	Parameterized.

Notes

- 1) All data in this section is based on the following ambient conditions: 120 degrees F (50 °C) maximum.
- 2) Forced air cooling is required to meet the maximum power ratings specified.
- 3) The amplifier module (SMA9807-1 and SMA9815-1) and 3-U version (SMA9815-3U) require an external DC power supply.

APPENDIX G


G - Matching motor phase leads to amplifier commands using Hall sensors.

Below you will find the steps necessary to insure that the command phases of a digital amplifier are properly matched to any three-phase motor that has Hall sensors. This method applies to a fully digital amplifier with digital current loops. Section labeled “System Setup” must have been completed before attempting this appendix.

Please read this procedure prior to working with the motor and amplifier.



It is intended that this procedure be done once by the engineering staff, whereupon they will incorporate the findings into production drawings, wiring labels and procedures.

- A) Locate or prepare the required equipment.
 1. A 2 channel oscilloscope
 2. A 3-phase Y-connected resistive load as illustrated below.
 3. A computer with MotionMaestro® installed.
- B) With the power off, connect the motor encoder outputs and the Hall sensor outputs to the amplifier. **Leave the motor power leads disconnected.** Connect the RS232 serial cable from the amplifier to the serial port on the computer (MotionMaestro®).






Specification for resistive load

- C) Apply power to the amplifier and establish communications between the amplifier and MotionMaestro®.
- D) Prepare the amplifier using the following dialogs.
 - 1.) Insure that the amplifier is in **current mode**. Deselect all modes except the **current mode**.
 - 2.) Set the analog command input signal gain to zero. Use the Setup Analog Input/Output dialog as shown.



Status
Enc. Index Sensed
Amp Enabled
HW Inhibit / Fault In
Soft Inhibit
Balancing
Commutated
Fault
At Speed
At Zero
Over Speed

Faults		  	
HS ECB		Hall	
LS ECB		Commutation	
Bus Over Volt		Bus Under Volt	
Amp Over Temp		CPLD	
Motor Temp		NV RAM	
Encoder			

- 3.) Check then clear all faults by referring to the Amplifier Faults and Amplifier Status displays on the toolbar. For example, if there is an External Inhibit status warning you must open the Setup Digital IO dialog and check the inhibit box, then fix all remaining amplifier faults. After all faults have been corrected a fault reset must be completed. You may perform a reset by typing RST at the terminal window or by opening the Control Panel and depressing the **"Fault Reset"** button. **Commutation alignment can not begin until all faults are cleared.**

- E) From the MotionMaestro® "Setup" menu, open the "Commutation" dialog and setup the following items:

The screenshot shows the 'Commutation' dialog box with the following settings circled:



- Motor:** Linear (radio button), Rotary (radio button), Number of Poles: 8, Lines per Revolution: 8192, Counts per Comm. Cycle: 8192.00, Scaling: 524288, Comm Count Rollover: 8192, Comm Cycles/CCR: 1.
- Init Method:** Hall (radio button), Twang (radio button), Dither (radio button), Init Current (amps): 2.14, Current slew rate: 4, Recovery Distance (deg): 0, Rotation Rate (deg/sec): 60.
- Phase Lead:** Angle Offset (deg): 0.00, Phase Lead (deg/KRPM): 0.00.
- Correction Method:** Hall Edge (radio button), Index-Auto (radio button), Index-Manual (radio button), None (radio button), Index Offset (deg): 0.00, Hall Signal Offset (deg): 0.00.

Other visible settings include: Encoder Data Position: 0, Encoder Reverse: unchecked, and buttons for 'Send Values to Amp' and 'Done'.

- 1) Motor type. Are you phasing a rotary or linear motor?
- 2) **Number of Poles.
- 3) **Encoder resolution.
- 4) Commutation angle offset = 0
(-30 degrees if Halls aligned phase to neutral?)
- 5) Commutation phase advance gain = 0
- 6) Init Method = Hall
- 7) Correction Method = Hall
- 8) Depress "Send Values To Amp" button


NOTE: ** Refer to Appendix F if motor Poles and Encoder Resolution are unknown.

- F) With the Commutation dialog still open, enable the amplifier. You will see on the amp, one segment lit on the seven segment display. This display segment indicates the Hall state. Rotate the motor shaft by hand, such that the segments rotate clockwise as viewed from the top of the drive. Verify the Encoder Data Position counts up in the Commutation dialog. If not, check the Encoder Data Reverse box. The Encoder Data Position should now count up as the seven segment display cycles clockwise.



- G) Save the new settings by selecting “Save to NVM” from the Setup menu. Answer Yes when prompted to save.

- H) Connect the 3-phase Y-connected resistor load to the **Motor** power leads for monitoring the motor back EMF (BEMF). **NOTE: do not connect the motor leads or the resistor load to the amplifier.**




- I) Connect the channel 1 scope probe to the amplifiers Analog Out pin. Connect the channel 1 scope common to the amplifiers Common pin. Set the channel 1 vertical scale to around **2V per division**. From the “Setup Analog Input/Output” dialog, Set the Analog Output Signal Source to “R Current Command” and directly below change the Analog Output Signal Gain to 100 percent.

3-phase Y-connected resistor load

- J) Connect the channel 2 scope probe to one of the motors leads. Connect the channel 2 scope common to the center of the Y-connected resistor load. Set the channel 2 vertical scale to around **2V per division**. Set the horizontal scale to around **100 ms per division**. Scaling may need to be changed in order to best see the data.

- K) Open the Control Panel. The square colored status box will give you the amplifier status. If the box is yellow or disabled then press the “Enable/Disable Amp” button. If the box is red the amp has a fault and must be cleared before you can proceed.


- L) From the Control Panel, apply a digital current command of **10 amps** to the amplifier. To do this you may have to expand the range that can be commanded from the control panel by selecting the Options button.



M) **Find the phase R motor lead.**

Rotate the motor by hand and verify the trace on channel 1 (phase R current command) follows a sinusoidal pattern. Move the channel 2 scope probe to each motor lead to determine which BEMF waveform is in phase or 180° out of phase with the phase R command. Label this lead Phase R.

NOTE: For each phase, R, S and T, one direction of rotation should cause the back EMF (BEMF) to be in phase with the command while the reverse rotation direction should cause the BEMF to be 180° out of phase. Determine which direction of rotation is in phase for the phase R motor lead, then rotate the motor in that same direction when determining the S and T motor leads. Once the phases are labeled, double check that the phase R and S motor leads result in waveforms that are in phase with the corresponding digital current commands on the amplifier when rotating the motor in the same direction for both.



ALSO: This method of matching motor leads to the amplifier requires that the motor's Hall sensors transitions are aligned with the motor phase to phase BEMF zero crossings. If the Hall sensors are aligned with the motor's phase to neutral BEMF, then the commutation offset angle must be set to ±30 degrees (you have to try both) before comparing the commands to the BEMF waveforms.

N) **Find the phase S motor lead.**

In MotionMaestro®, change the Analog Output Signal Source *S Current Command*. Place the channel 2 scope probe on one of the two remaining motor leads. Rotate the motor in the same direction that was used for phase R above. Determine which of the remaining two leads of the motor result in a waveform that is in phase with the phase S command. Label this lead Phase S. Move the channel 2 probe to the remaining motor lead.

O) **Find the phase T motor lead.**


Same procedure as above with the analog output source set to *T Current Command*. If phase R and phase S were properly found, phase T will be the remaining motor wire. Label this lead phase T.

P) Set the current command back to **0** by clicking the **STOP** button on the **Control Panel**. Reset any current limits, foldback thresholds to the desired operational settings. Reset the Control Panel options to appropriately safe values. Set the Analog Input Signal Gain back to the desired operational value.

Q) Save the settings by selecting "Save to NVM" from the Setup menu.

R) Remove the amplifier's power. Remove the scope probes. Connect the motor R, S, and T leads to the amplifier's R, S, and T terminals respectively.

- S) Apply power to amplifier. The amplifier should still be in **Current Mode** and **Enabled** (unless the external inhibit is active). From the Control Panel, see following picture, issue a digital current command of **0.5 to 2 amps**, enough so the motor begins to rotate.
- T) While the motor is rotating, verify that the sign of the actual velocity matches the sign of the commanded current. If NOT mark the **Tach Reverse** checkbox on the control panel and verify that the signs now match. Command the opposite polarity current to the motor, **-5 to -2.0 amps** and verify that the motor reverses direction and runs at approximately the same speed. The signs of the current command and actual velocity should still match.
- U) Set the current command back to 0 by clicking on the **STOP** button of the Control Panel. Save the settings by selecting "Save to NVM" from the setup menu.



The motor should now be properly commutated and phased.


APPENDIX H

H – Determining Encoder Resolution and Number of Poles.

A) Encoder Resolution

From the MotionMaestro® Status menu, open the “Control Loop Signals” dialog . Check the box that allows you to monitor “Measured” “position” of the encoder, then mark a start position on the motor shaft. Turn the shaft 360 degrees clockwise and monitor the encoder position in the Control Loop Signals dialog. Note the change in encoder counts. Take the change in encoder counts per 1 revolution (360 degrees) and divide by four (4). This is your Lines of Resolution that you will enter in your Commutation dialog. (Note: For better accuracy, you may rotate by 10 turns and divide by 40 instead of 4.)

Common encoder line counts include but are not limited to 250, 256, 500, 512, 1000, 1024, 2000, 2048, 2500, 4096, 5000, 8192, and 10,000 lines/revolution.




B) Number of Poles (Note: requires Hall sensors)

Enable the amplifier. Mark a start position on the motor shaft. You will be monitoring the seven segment display on the amplifier as shaft is rotated. Note the lit segment before rotating the motor shaft, now turn the shaft 360 degrees clockwise. As you are rotating shaft, count the number of times the seven segment display goes through a full led rotation. Take the number of full LED cycles and multiply by two. This is the Number of Poles that you will enter in your Commutation dialog.


APPENDIX I

I – Commutation track signals and phase-to-phase BEMF.



Encoder Outputs

The following illustrates the encoder signals for a standard Glentek motor that is correctly commutated where the encoder is not reversed (FER=0) and the tachometer feedback is reversed (TR=1).



APPENDIX J

J – European Union EMC Directives

Electromagnetic Compatibility Guidelines For Machine Design

This document provides background information about Electromagnetic Interference (EMI) and machine design guidelines for Electromagnetic Compatibility (EMC).

Introduction

Perhaps no other subject related to the installation of industrial electronic equipment is so misunderstood as electrical noise. The subject is complex and the theory easily fills a book. This section provides guidelines that can minimize noise problems.

The majority of installations do not exhibit noise problems. However, these filtering and shielding guidelines are provided as counter measures. The grounding guidelines provided below are simply good grounding practices. They should be followed in all installations.

Electrical noise has two characteristics: generation or emission of electromagnetic interference (EMI); and response or immunity to EMI. The degree to which a device does not emit EMI, and is immune to EMI is called the device's Electromagnetic Compatibility (EMC).

Equipment, which is to be brought into the European Union legally, requires a specific level of EMC. Since this applies when the equipment is brought into use, it is of considerable importance that a drive system, as a component of a machine, be correctly installed.

"EMI Source-Victim Model" shows the commonly used EMI model. The model consists of an EMI source, a coupling mechanism and an EMI victim. A device such as servo drives and computers, which contain switching power supplies and microprocessors, are EMI sources. The mechanisms for the coupling of energy between the source and victim are conduction and radiation. Victim equipment can be any electromagnetic device that is adversely affected by the EMI coupled to it.




Figure 1- EMI Source-Victim Model

Immunity to EMI is primarily determined by equipment design, but how you wire and ground the device is also critical to achieving EMI immunity. Therefore, it is important to select equipment that has been designed and tested for industrial environments. The EMI standards for industrial equipment include the EN61000-4-X series (IEC 1000-4-X and IEC801-X), EN55011 (CISPR11), ANSI C62 and C63 and

MIL-STD-461. Also, in industrial environments, you should use encoders with differential driver outputs rather than single ended outputs, and digital inputs/outputs with electrical isolation, such as those provided with optocouplers.

The EMI model provides only three options for eliminating the EMC problem:

- Reduce the EMI at the source,
- Increase the victim's immunity to EMI (harden the victim),
- Reduce or eliminate the coupling mechanism,

In the case of servo drives, reducing the EMI source requires slowing power semiconductor switching speeds. However, this adversely affects drive performance with respect to heat dissipation and speed/torque regulation. Hardening the victim equipment may not be possible, or practical. The final and often the most realistic solution is to reduce the coupling mechanism between the source and victim. Filtering, shielding and grounding can achieve this.

Filtering

As mentioned above, high frequency energy can be coupled between circuits via radiation or conduction. The AC power wiring is one of the most important paths for both types of coupling mechanisms. The AC line can conduct noise into the drive from other devices, or it can conduct noise directly from the drive into other devices. It can also act as an antenna and transmit or receive radiated noise between the drive and other devices.

One method to improve the EMC characteristics of a drive is to use an isolation AC power transformer on the amplifier's input power. This minimizes inrush currents on power-up and provides electrical isolation. In addition, it provides common mode filtering, although the effect is limited in frequency by the interwinding capacitance. Use of a Faraday shield between the windings can increase the common mode rejection bandwidth, (shield terminated to ground) or provide differential mode shielding (shield terminated to the winding). In some cases an AC line filter will not be required unless other sensitive circuits are powered off the same AC branch circuit.

NOTE: "Common mode" noise is present on all conductors that are referenced to ground. "Differential mode" noise is present on one conductor referenced to another conductor.

The use of properly matched AC line filters to reduce the conducted EMI emitting from the drive is essential in most cases. This allows nearby equipment to operate undisturbed. The basic operating principle is to minimize the high frequency power transfer through the filter. An effective filter achieves this by using capacitors and inductors to mismatch the source impedance (AC line) and the load impedance (drive) at high frequencies.

For drives brought for use in Europe, use of the correct filter is essential to meet emission requirements. Detailed information on filters is included in the manual and transformers should be used where specified in the manual.

AC Line Filter Selection

Selection of the proper filter is only the first step in reducing conducted emissions. Correct filter installation is crucial to achieving both EMI attenuation and to ensure safety. All of the following guidelines should be met for effective filter use.

- 1) The filter should be mounted to a grounded conductive surface.
- 2) The filter must be mounted close to the drive-input terminals, particularly with higher frequency emissions (5-30 MHz). If the distance exceeds 600mm (2 feet), a strap should

be used to connect the drive and filter, rather than a wire.

- 3) The wires connecting the AC source to the filter should be shielded from, or at least separated from the wires (or strap) that connects the drive to the filter. If the connections are not segregated from each other, then the EMI on the drive side of the filter can couple over to the source side of the filter, thereby reducing, or eliminating the filter effectiveness. The coupling mechanism can be radiation, or stray capacitance between the wires. The best method of achieving this is to mount the filter where the AC power enters the enclosure. "AC Line Filter Installation" shows a good installation and a poor installation.





Figure 2- AC Line Filter Installation

When multiple power cables enter A unfiltered line can contaminate a filtered line external to the enclosure. Therefore, all lines must be filtered to be effective. The situation is similar to a leaky boat. All the holes must be plugged to prevent sinking.

	<p style="text-align: center;">WARNING</p> <p>Large leakage currents exist in AC line filters. They must be grounded properly before applying power. Filter capacitors retain high voltages after power removal. Before handling the equipment, voltages should be measured to determine safe levels prior to handling the equipment. Failure to observe this precaution could result in severe bodily injury.</p>
---	---

If the filter is mounted excessively far from the drive, it may be necessary to mount it to a grounded conductive surface, such as the enclosure, to establish a high frequency (HF) connection to that surface. To achieve the HF ground, direct contact between the mounting surface and the filter must be achieved. This may require removal of paint or other insulating material from the cabinet or panel.

The only reasonable filtering at the drive output terminals is the use of inductance. Capacitors would slow the output switching and deteriorate the drive performance. A common mode choke can be used to reduce the HF voltage at the drive output. This will reduce emission coupling through the drive back to the AC line. However, the motor cable still carries a large HF voltage and current. Therefore, it is very important to segregate the motor cable from the AC power cable. More information on cable shielding and segregation is contained in the section on shielding.

Grounding

High frequency (HF) grounding is different from safety grounding. A long wire is sufficient for a safety ground, but is completely ineffective as a HF ground due to the wire inductance. As a rule of thumb, a wire has an inductance of 8 nH/in regardless of diameter. At low frequencies it acts as constant impedance, at intermediate frequencies as an inductor, and at high frequencies as an antenna. The use of ground straps is a better alternative to wires. However the length to width ratio must be 5:1, or better yet 3:1, to remain a good high frequency connection.

The ground system's primary purpose is to function as a return current path. It is commonly thought of as an equipotential circuit reference point, but different locations in a ground system may be at different potentials. This is due to the return current flowing through the ground system's finite impedance. In a sense, ground systems are the sewer systems of electronics and as such are sometimes neglected.

The primary objective of a high frequency ground system is to provide a well-defined path for HF currents and to minimize the loop area of the HF current paths. It is also important to separate HF grounds from sensitive circuit grounds. "Single Point Ground Types" shows single point grounds for both series (daisy chain) and parallel (separate) connections. A single point, parallel connected ground system is recommended.




Figure 3-Single Point Ground Types

A ground bus bar or plane should be used as the "single point" where circuits are grounded. This will minimize common (ground) impedance noise coupling. The ground bus bar (GBB) should be connected to the AC ground, and if necessary, to the enclosure. All circuits or subsystems should be connected to the GBB by separate connections. These connections should be as short as possible and straps should be used when possible. The motor ground conductor must return to the ground terminal on the drive, not the GBB.

Shielding and Segregation

The EMI radiating from the drive enclosure drops off very quickly over distance. Mounting the drive in an enclosure, such as an industrial cabinet, further reduces the radiated emissions. The cabinet should have a high frequency ground and the size of the openings should be minimized. In addition, the drive is considered an "open" device that does not provide the proper IP rating for the environment in which it is installed. For this reason the enclosure must provide the necessary degree of protection. An IP rating or Nema rating (which is similar to IP) specifies the degree of protection that an enclosure provides.

The primary propagation route for EMI emissions from a drive is through cabling. The cables conduct the EMI to other devices, and can also radiate the EMI. For this reason, cable segregation and shielding are important factors in reducing emissions. Cable shielding can also increase the level of immunity for a drive. For example:

- Shield termination at both ends is extremely important. The common misconception that shields should be terminated at only one end originates from audio applications with frequen-

cies <20 kHz. RF applications must be terminated with the shield at both ends, and possibly at intermediate points for exceptionally long cables.

- When shielded cables are not terminated at the cable connection and pass through the wall of a cabinet, the shield must be bonded to the cabinet wall to prevent noise acquired inside the cabinet from radiating outside the cabinet, and vice versa.
- When shielded cables are terminated to connectors, the shield must be able to provide complete 360° coverage and terminate through the connector backshell. The shield must not be grounded inside the connector through a drain wire. Grounding the shield inside the connector couples the noise on the shield to the signal conductors sharing the connector and virtually guarantees failure to meet European EMC requirements.
- The shield must be continuous. Each intermediate connector must continue the shield connection through the backshell.
- All cables, both power and signal should use twisted wire pairing.

The shield termination described above provides a coaxial type of configuration, which provides magnetic shielding, and the shield provides a return path for HF currents that are capacitively coupled from the motor windings to the frame. If power frequency circulating currents are an issue, a 250 VAC capacitor should be used at one of the connections to block 50/60 Hz current while passing HF currents. Use of a properly shielded motor cable is essential to meet European EMC requirements.

The following suggestions are recommended for all installations.

1. Motor cables must have a continuous shield and be terminated at both ends. The shield must connect to the ground bus bar or drive chassis at the drive end, and the motor frame at the motor end. Use of a properly shielded motor cable is essential to meet European EMC requirements.
2. Signal cables (encoder, serial, and analog) should be routed away from the motor cable and power wiring. Separate steel conduit can be used to provide shielding between the signal and power wiring. Do not route signal and power wiring through common junctions or raceways.
3. Signal cables from other circuits should not pass within 300 mm (1 ft.) of the drive.
4. The length or parallel runs between other circuit cables and the motor or power cable should be minimized. A rule of thumb is 300 mm (1 ft.) of separation for each 10 m (30 ft.) of parallel run. The 300 mm (1 ft.) separation can be reduced if the parallel run is less than 1 m (3 ft.).
5. Cable intersections should always occur at right angles to minimize magnetic coupling.
6. The encoder mounted on the brushless servomotor should be connected to the amplifier with a cable using multiple twisted wire pairs and an overall cable shield. Encoder cables are offered in various lengths that have correct terminations.

Persistent EMI problems may require additional countermeasures. The following suggestions for system modification may be attempted.

1. A ferrite toroid or “doughnut” around a signal cable may attenuate common mode noise, particularly RS-232 communication problems. However, a ferrite toroid will not help differential mode noise. Differential mode noise requires twisted wire pairs.

2. Suppress each switched inductive device near the servo amplifier. Switch inductive devices include solenoids, relay coils, starter coils and AC motors (such as motor driven mechanical timers).
3. DC coils should be suppressed with a “free-wheeling” diode connected across the coil.
4. AC coils should be suppressed with RC filters (a 200 Ohm 1/2 Watt resistor in series with a 0.5 uF, 600 Volt capacitor is common).

Following these guidelines can minimize noise problems. However, equipment EMC performance must meet regulatory requirements in various parts of the world, specifically the European Union. Ultimately, it is the responsibility of the machine builder to ensure that the machine meets the appropriate requirements as installed.

RECOMMENDATIONS FOR GLENTEK AMPLIFIERS

All amplifiers installed in a NEMA 12 enclosures or equivalent with wiring in metal conduit or enclosed metal wire trough (see Shielding and segregation).

Use Glentek shielded feedback and motor cables.

An AC line filter properly installed in a NEMA 12 enclosure or equivalent (see Filtering).

AC line filters for single-phase applications

1A-15A	input current, 120-250VAC use: Corcom 15ET1 or equivalent.
15A-25A	input current, 120-250VAC use: Corcom 25FC10 or equivalent.
25A-36A	input current, 120-250VAC use: Corcom 36FC10 or equivalent.

AC line filters for 3-phase applications

1A-25A	input current, 120-250VAC use: Corcom 25FCD10 or equivalent.
25A-36A	input current, 120-250VAC use: Corcom 36FCD10 or equivalent.
36A-50A	input current, 120-250VAC use: Corcom 50FCD10 or equivalent.
50A-80A	input current, 120-250VAC use: Corcom 80FCD10 or equivalent.



Declaration of Conformity

This document certifies that the products listed below and their accessories comply with the following Directives and Standards when installed and operated in accordance with the instructions provided in the operation and installation manual. EMC Testing, Product Safety Evaluations and Risk Assessments were conducted by National Technical Systems (an independent Nationally recognized Test Laboratory) and Glentek, Inc.

European Council Directives:

- 89/336/EEC (Electromagnetic Compatibility (EMC) Directive).
- 8/37/EC (formerly 89/392/EEC) (Machinery Directive).

Standards to which conformity is declared:

- EN50081-2: 1994
- EN50082-2: 1995
- EN60204-1: 1997

Manufacturers Name: Glentek, Inc.

Manufacturers Address: 208 Standard Street, El Segundo, California, 90245, USA

Description of Equipment: PWM (Pulse Width Modulated) Servo Amplifiers

Model Numbers:

- 1) SMA9815, SMA9815LP and SMA9815HP. These amplifiers packaged in the following configurations: -1, -1A-1, -2A-1, -2A-2, -4A-3, -4A-4, -3U and all the power supply configurations: 00, 01, 02.
- 2) SMA9807. This amplifier packaged in the following configurations: -1, -1A-1, -2A-1, -2A-2, -4A-3, -4A-4
- 3) SMA9830. This amplifier packaged in the following configuration: -1A-1

The undersigned hereby declares that the equipment specified above conforms to the noted Directives and Standards.

Manufacturer

Helen M. Vasak
Secretary-Treasurer
Date: October 19, 2001

APPENDIX K

K - Amplifier Terms and Technology

This appendix contains information that describes and explains the terms and concepts referred to in this manual. The information contained here is generic to amplifiers and motion control technology in general and does not apply specifically to the SMA9800 series amplifiers. The TERMS section is a glossary that defines the terms used when discussing amplifiers. The TECHNOLOGY section describes methods or concepts that involves the usage of multiple terms.

TERMS

Analog Current Command Mode

Analog current mode, also called Torque mode or Current mode, indicates that the amplifier is being commanded by an analog signal and that the amplifiers' control loop is controlling current. This command mode is used when one needs to control torque. The analog signal, in volts, is a scaled representation of desired current as measure at the output. For instance -10 volts to 10 volts at the analog input becomes -15 amps to 15 amps at the amplifiers output. The scaling is different for different amplifiers.

Analog Velocity Command Mode

Analog velocity mode indicates that the amplifier is being commanded by an analog signal and that the amplifiers' control loop is controlling velocity. This command mode is used when one needs to control the speed of some device. The analog signal, in volts, is a scaled representation of desired velocity as measured at the output. For instance -10 volts to 10 volts at the analog input becomes -3000 rpm to 3000 rpm at the device being moved. The scaling is can often be configured by the application engineer.

Command Mode

A term used to refer to the method by which a command is given to an amplifier. The amplifier uses this command in its' control loop as a target to be achieved. The command mode usually includes how the amplifier is to interpret the command. That is, is the command to represent current, velocity or position. There are many forms and methods by which commands are submitted to an amplifier. Traditionally the command was given as an analog voltage input to the amplifier. Today there is analog, digital, serial communications or some combination of these.

Commutation

Commutation is the term used to describe the method by which current is applied to the windings of a motor such that the applied current moves the motor in a desired direction, or to a desired position, with the minimum current. Brushes are the method of commutation in a brush motor. In a three phase brushless motor, Sinusoidal Commutation is the usual method of commutation. See Sinusoidal Commutation.

Commutation Initialization Method

In order to properly commute a brushless motor, the servo drive must know the absolute position of the rotor with respect to the motor windings in the stator. Since incremental shaft encoders only supply "relative" rotor position, the servo drive must perform a power-on, phase-finding scheme to determine the absolute position of the shaft. This is known as commutation initialization. Once the absolute position is determined, the position from the encoder can be used to maintain the absolute position. The SMA9800 amplifiers have three power-on commutation initialization methods available for finding the

absolute position of the rotor. The first two methods, Twang and Dither, require the rotor to move; the third scheme, Hall, does not require motion. The Hall method does require the addition of Hall sensors or commutation tracks. Commutation tracks are simulated Hall sensors built into the shaft encoder.

Dither Commutation Initialization

Dither commutation initialization is a method that moves the motor multiple times in a search to find and set the initial commutation angle of a brushless motor. Dither relies on rotating the electrical angle of the applied current until it aligns with the electrical angle of the rotor. In Dither initialization, at power up, the amplifier guesses at the location of the rotor and applies a set of currents to the motor according to this guess. If the guess is wrong, the motor will start to accelerate. Once the direction of the rotor acceleration is detected, the servo drive knows the rotor location within 180 electrical degrees. The servo drive then updates its guess by ± 90 electrical degrees, depending upon the direction of the acceleration, and applies a new set of currents. Once the servo drive determines the new direction of the acceleration, it knows the rotor location within 90 electrical degrees. It then updates its guess by ± 45 electrical degrees, depending upon the direction of the acceleration, and applies yet another set of currents. The servo drive continues to update its guess of the electrical angle of the motor each time, cutting the possible region in half until finally it does not detect any more acceleration, indicating that the shaft location has been found.

This method is referred to as “Dither” because the shaft will tend to oscillate as the servo drive keeps updating its guess of the shaft location. The size of the oscillations will depend upon the amount of current applied during this search and how far the initial guess is off from the actual rotor position. Typically these oscillations are very small and occur very quickly, therefore very little motion occurs.

Hall Commutation Initialization

Hall commutation initialization is a method that relies on sensors to give an approximation of the initial commutation angle of a motor. Hall initialization uses Hall sensors or commutation tracks (simulated Hall sensors built into the shaft encoder) to determine the rotor angle. In a brushless motor three Hall sensors are used to detect rotor position. The three Hall sensors employed are commonly named U, V and W; S1, S2 and S3; or A, B and C. The I sensors are digital (on/off) devices and therefore the combination of the three can result in eight different states. The sensors are aligned with the motor in a way that causes the output of the sensors to transition through six of the eight possible states as the motor is rotated through 360 electrical degrees. Each Hall state corresponds to 60 electrical degrees. Only one sensor changes states at any given transition.

At power up, the servo drive reads the state of the Hall sensors and from this state can determine within ± 30 electrical degrees where the motor shaft is located. This is close enough to start commutating the motor, so the servo drive uses this approximation as the actual rotor position. Once motion is commanded (position, velocity or torque), the servo drive starts commutating with this value and watches for a transition of the Halls state. Upon this transition, the servo drive knows the exact location of the rotor shaft and updates the commutation angle based on this known location.

This method, unlike Twang or Dither, does not move the rotor shaft at power up. Instead, it uses a non-optimal commutation angle at start-up and corrects to the optimal commutation angle upon the first Hall state transition once motion is commanded.

Phase Lead

Phase lead is a gain applied to the commutation angle based on the velocity of the motor. Units are usually in degrees of commutation angle per 1000 rpm (degrees/krpm). Usually the phase angle is advanced for a positive velocity. An ideal phase lead at a given rpm in a specific application will minimize current in the motor. Phase lead is useful in applications where a velocity is held constant for a long period of time, particularly if the velocity is held at or near the rated speed of the motor. Spindle motors are a good application where phase lead is used. Appropriately used phase lead will reduce power

consumption. This being said, most applications do not make use of phase lead.

Sinusoidal Commutation

In sinusoidal commutation a sinusoidal current is applied to each phase of the motor to cause the motor to rotate. In a three phase motor, the relationship of the currents applied in the three phases for a positive rotation of the rotor is:

$$\begin{aligned} I_R(\theta_e) &= I * \sin(\theta_e), \\ I_S(\theta_e) &= I * \sin(\theta_e - 120^\circ), \\ I_T(\theta_e) &= I * \sin(\theta_e - 240^\circ); \end{aligned}$$

where:

I_R , I_S , and I_T are the currents applied to phase R, S, and T respectively,
 I is the amplitude of the commanded current,
 θ_e is the "electrical angle" of the applied currents.

The relationship between the electrical angle, θ_c , and the mechanical angle (the angle of the rotor), θ_m , is:

$$\theta_m = \theta_c \times 2/N,$$

where

N is the number poles in the motor.

For example, a 4-pole motor (two North poles and two South poles) will rotate 180 mechanical degrees as the currents applied are varied through 360 electrical degrees.

Twang Commutation Initialization

Twang commutation initialization is a method that moves the motor twice to find and set the initial commutation angle of a brushless motor. When a fixed set of motor currents is applied to the three phases of the motor, the rotor will rotate to an electrical angle with a known relationship to the applied current. Since there are $N/2$ (N is the number of motor poles) electrical cycles per mechanical revolution of the motor, the actual rotor position can be 1 of $N/2$ mechanical locations. In "Twang" initialization, at power up, the servo drive applies current to all three motor phases in such a way that the motor rotor is forced to move to a known electrical position with respect to the stator. The rotor position can actually end up in one of two locations: The first is a stable equilibrium position and the second is an unstable equilibrium position. Since the servo drive cannot be certain at which of these two points the motor has stopped, it applies a second set of currents which will rotate the motor to another known location. This location will always be a stable equilibrium position and therefore results in one unique initial commutation angle.

The first set of currents applied will cause the rotor shaft to rotate up to ± 180 electrical degrees ($\pm 180 \times 2/N$ mechanical degrees). The second set of currents will cause the motor to rotate either 60 or 120 electrical degrees, depending upon which of the two locations the motor stopped at when the first set of currents was applied.

TECHNOLOGY

Selection of a commutation initialization method

The first step in selecting a commutation initialization method is to determine whether motion can be tolerated upon power up. If motion is not acceptable, then the motor must be equipped with Hall sensors or commutation tracks and Hall initialization should be used. If motion is acceptable at power up, then the second item which will prevent Twang initialization and Dither initialization from working properly is the presence of large external torque applied on the motor rotor. If large external torque exist which either resist rotor motion (such as a break or excessive friction), or cause the rotor to rotate (such as a gravity), then Twang and Dither can result in a non-optimal commutation angle. This occurs because these modes both rely upon finding equilibrium between the applied motor current and the rotor position; an external torque will alter this equilibrium position. If a large enough current is applied during initialization, this external torque can be overcome and an acceptable commutation angle can be achieved.

If motion is acceptable on power up and external torque is minimal, then either Twang or Dither initialization can be used. Dither is the quickest and requires the least motion. As the motion is very different between these two modes, the operator should try each one and determine which works best for his application.

If Twang or Dither initialization is selected, the amount of current applied to the motor during initialization must be set. This value can be set from MotionMaestro's commutation dialog. Typical values range from 2.5 amps to 5.0 amps. This value should be set as small as possible while still being large enough to overcome external torque. If too small a value is used, the motor will not be optimally commutated, and this will result in rough motion and larger than normal current required to move the motor.

APPENDIX L

L - Amplifier Model Numbering

This appendix explains the model numbering system for Glentek's Omega Series Digital servo amplifiers. The model numbering system is designed so that you, our customer, will be able to quickly and accurately create the model number for the amplifier that best suits your needs. This manual contains complete model numbering information for the following amplifier types:

SMA9807

SMA9815

SMA9830

In order to minimize confusion, the above three amplifier types have their own respective model numbering sections on the pages that follow. In order to accurately select a complete part number, please follow the steps shown below:

1. Select the amplifier type which meets your power requirements (i.e. SMA9807, SMA9815 or SMA9830) and proceed to that section of model numbering.
2. Select the industry standard mounting configuration which meets your needs (i.e. 3U Plug-In, Module, Stand Alone or Multi-Axis).
3. Utilize the model number key in conjunction with the tables at the beginning of each section to select the complete model number for your requirements. Note: A complete model number example follows the model number key and includes a full description of the individual codes which make up the complete model number.

SMA9807 Amplifier Model Numbering

The following tables are used to fill in the different parts of the model number. Refer to these when constructing a model number for your requirements.

XXX	Power Input Voltage	Package Type	Continuous Current (Amps)	Peak Current (Amps)
000	135 - 260VAC	Stand Alone	07	14
003	50 - 135VAC	Stand Alone	07	14
006	22 - 50VAC	Stand Alone	07	14
100	190 – 370VDC	Module	07	14
103	70 – 190VDC	Module	07	14
106	30 – 70VDC	Module	07	14

YYY	Logic Board Description	Connector
001	Full Feature	RJ45
003	Reduced Wire Encoder (Sanyo Denki and Tamagawa)	RJ45
005	Yaskawa Encoder	RJ45
007	Pulse Follower	RJ45
009	2 phase Current Mode	RJ45

MM	Mounting
omit	1 - axis Module
1A	1 - axis Stand Alone
2A	2 - axis Chassis
4A	4 - axis Chassis

N	Number of Amplifiers Installed
1	1 Amplifier
2	2 Amplifiers
3	3 Amplifiers
4	4 Amplifiers

F	Fan Power
1	115VAC
2	230VAC


SMA9807 Amplifier Module

SMA9807 - XXX - YYY - 1

Model number key:

- SMA9807** Designates an Omega Series fully digital Surface Mount Amplifier.
- XXX** Power board Configuration Code.
- YYY** Logic board Configuration Code.
- 1** Single amplifier module.

Example:




SMA9807 Stand Alone Amplifier

SMA9807 - XXX - YYY - 1A - 1

Model number key:

- SMA9807** Designates an Omega Series fully digital Surface Mount Amplifier.
- XXX** Power board Configuration Code.
- YYY** Logic board Configuration Code.
- 1A** Mounting Configuration Code, Single axis Stand Alone.
- 1** Single amplifier module.

Example:




SMA9807 Multi - Axis Amplifier

SMA9807 - XXX - YYY - MM - N - F

Model number key:

SMA9807	Designates an Omega Series fully digital Surface Mount Amplifier.
XXX	Power board Configuration Code.
YYY	Logic board Configuration Code.
MM	Mounting Configuration Code.
N	Number of amplifiers installed.
F	Fan Power.

Example:



SMA9815 Amplifier Model Numbering

The following tables are used to fill in the different parts of the model number. Refer to these when

XXX	Power	Power Input Voltage		Continuous Current (Amps)	Peak Current (Amps)
		Module (VDC)	Stand Alone / Chassis (VAC)		
000	Standard	190 - 370	208 - 240	15	30
001	High	190 - 370	208 - 240	20	40
002	Low	190 - 370	208 - 240	10	20
003	Standard	70 - 190	110 - 130	15	30
004	High	70 - 190	110 - 130	20	40
005	Low	70 - 190	110 - 130	10	20
006	Standard	30 - 70	Not Available	15	30
007	High	30 - 70	Not Available	20	40
008	Low	30 - 70	Not Available	10	20

YYY	Logic Board Description	Connector
000	Full Feature	DB9
001*	Full Feature	RJ45
002	Reduced Wire Encoder (Sanyo Denki and Tamagawa)	DB9
003*	Reduced Wire Encoder (Sanyo Denki and Tamagawa)	RJ45
004	Yaskawa Encoder	DB9
005*	Yaskawa Encoder	RJ45
006	Pulse Follower	DB9
007*	Pulse Follower	RJ45
008	2 phase Current Mode	DB9
009*	2 phase Current Mode	RJ45

MM	Mounting
Omit	1 - axis Module
1A	1 - axis Stand Alone
2A	2 - axis Chassis
4A	4 - axis Chassis

N	Number of Amplifiers Installed
1	1 Amplifier Installed
2	2 Amplifiers Installed
3	3 Amplifiers Installed
4	4 Amplifiers Installed

F	Fan Power
1	115VAC
2	230VAC

* Not available in 3U Plug-In Amplifier


SMA9815 Amplifier Module Numbering Key

SMA9815 - XXX - YYY - 1

Model number key:

- SMA9815** Designates an Omega Series fully digital Surface Mount Amplifier.
- XXX** Power board Configuration Code.
- YYY** Logic board Configuration Code.

Example:




SMA9815 Stand Alone Amplifier

SMA9815 - XXX - YYY - 1A - 1

Model number key:

- SMA9815** Designates an Omega Series fully digital Surface Mount Amplifier.
- XXX** Power board Configuration Code.
- YYY** Logic board Configuration Code.
- 1A** Mounting Configuration Code, Single axis Stand Alone.
- 1** Single amplifier module.

Example:




SMA9815 Multi - Axis Amplifier

SMA9815 - XXX - YYY - MM - N - F

Model number key:

- SMA9815** Designates an Omega Series fully digital Surface Mount Amplifier.
- XXX** Power board Configuration Code.
- YYY** Logic board Configuration Code.
- MM** Mounting Configuration Code.
- N** Number of amplifiers installed.
- F** Fan Power..

Example:




SMA9815-3U Plug-In Amplifier

SMA9815 - XXX - YYY - 3U

Model number key:

- SMA9815** Designates an Omega Series fully digital Surface Mount Amplifier..
- XXX** Power board Configuration Code.
- YYY** Logic board Configuration Code.
- 3U** 3U Plug-In Amplifier.

Example:



SMA9830 Amplifier Model Numbering

The following tables are used to fill in the different parts of the model number. Refer to these when constructing a model number for your requirements.

XXX	Power Input Stand Alone (VAC)	Continuous Current (Amps)	Peak Current (Amps)
000	208 - 240	30	60
003	110 - 130	30	60

YYY	Logic Board Description	Connector
000	Full Feature	DB9
001	Full Feature	RJ45
002	Reduced Wire Encoder (Sanyo Denki and Tamagawa)	DB9
003	Reduced Wire Encoder (Sanyo Denki and Tamagawa)	RJ45
004	Yaskawa Encoder	DB9
005	Yaskawa Encoder	RJ45
006	Pulse Follower	DB9
007	Pulse Follower	RJ45
008	2 phase Current Mode	DB9
009	2 phase Current Mode	RJ45

SMA9830 Stand Alone Amplifier

SMA9830 - XXX - YYY - 1A - 1

Model number key:

SMA9830 Designates an Omega Series fully digital Surface Mount Amplifier.

XXX Power board Configuration Code.


YYY Logic board Configuration Code.

1A Mounting Configuration Code, Single axis Stand Alone.

1 Single amplifier module.

Example:

SMA9830 - 000 - 004 - 1A - 1



Appendix M

Factory Repair & Warranty

Factory Repair

Should it become necessary to return an servo drive to Glentek for repair, please follow the procedure described below:

1. Reassemble the unit, if necessary, making certain that all the hardware is in place.
2. Tag the unit with the following information:
 - A. Serial number and model number.
 - B. Company name, phone number, and name of representative returning the unit.
 - C. A brief notation explaining the malfunction.
 - D. Date the unit is being returned.
3. Repackage the unit with the same care and fashion in which it was received. Label the container with the appropriate stickers (e.g.: FRAGILE: HANDLE WITH CARE).
4. Contact a Glentek representative, confirm that the unit is being returned to the factory and obtain an RMA (Return Material Authorization) number. The RMA number must accompany the unit upon return to Glentek.
5. Return the unit by the best means possible. The method of freight chosen will directly affect the timeliness of its return.

Glentek also offers a one-day repair service in the unlikely event that your system is down and you do not have a replacement servo drive module.

Warranty

Any product, or part thereof, manufactured by Glentek, Inc., described in this manual, which under normal operating conditions, in the plant of the original purchaser, thereof proves defective in material or workmanship within one year from the date of shipment by us, as determined by an inspection by us, will be repaired or replaced free of charge, FOB our factory, El Segundo, California, U.S.A. provided that you promptly send to us notice of the defect and establish that the product has been properly installed, maintained, and operated within the limits of rated and normal usage, and that no factory sealed adjustments have been tampered with. Glentek's liability is limited to repair or replacement of defective parts.


Any product or part manufactured by others and merely installed by us, such as an electric motor, etc., is specifically not warranted by us and it is agreed that such product or part shall only carry the warranty, if any, supplied by the manufacturer of that part. It is also understood that you must look directly to such manufacturer for any defect, failure, claim or damage caused by such product or part.

Under no circumstances shall Glentek, Inc. or any of our affiliates have any liability whatsoever for claims or damages arising out of the loss of use of any product or part sold to you. Nor shall we have any liability to yourself or anyone for any indirect or consequential damages such as injuries to person and property caused directly or indirectly by the product or part sold to you, and you agree in accepting our product or part to save us harmless from any and all such claim


APPENDIX N

N– Drawings

SMA9807-1	Amplifier Module (9807-1033-000-A)
SMA9807-1A-1	Stand alone amplifier (9807-1033-000-A)
SMA9807-2A-2	2 axis base plate chassis installation (9807-1035-000-A)
SMA9807-4A-4	4 axis base plate chassis installation (9807-1034-000-A)
SMA9815-1	Amplifier module (9815-1030-000-B)
SMA9815-3U	3U plug-in amplifier (9515-1030-000-A)
SMA9815-1A-1	Stand alone amplifier (9815-1031-000-B)
SMA9815-2A-2	2 axis base plate chassis installation (9815-1032-000-B)
SMA9815-4A-4	4 axis base plate chassis installation (9815-1033-000-B)
SMA9830-1A-1	Stand alone amplifier (9830-1030-000-A)









2 AXIS BASEPLATE
P/N: 9807-1036-000


- NOTES:
1. USE SHIELDED CABLE FOR COMMAND SIGNAL.
 2. NEVER GROUND THE OUTPUTS OF THE AMPLIFIERS.
 3. FAN POWER IS 110-130VAC, ALL MODELS.
 4. MAXIMUM HEIGHT=6.25"


3	FAN/201	SEE NOTES			EA	1
2	PS/201	GPB600-50 POWER SUPPLY			EA	1
1	AT-AZ	SM98007 BRUSH TYPE SERVO AMPLIFIERS			EA	2
ITEM GLENTEK PART NUMBER		MATERIAL DESCRIPTION		UNIT QUANTITY		
LIST OF PARTS LIST						
<div> <div> THE INFORMATION CONTAINED HEREIN IS UNCLASSIFIED EXCEPT WHERE SHOWN OTHERWISE. IT IS THE PROPERTY OF GLENTEK INC. AND IS NOT TO BE DISCLOSED TO OTHERS WITHOUT THE WRITTEN PERMISSION OF GLENTEK INC. </div> <div>  <p>208 Standard Street El Segundo, CA 90224 USA 310.322.3005 FAX 310.322.1709 www.glenetek.com</p> </div> </div>						
UNLESS OTHERWISE SPECIFIED: MODEL: SM98007 DIMENSIONS ARE IN INCHES TOLERANCES ARE:		DRAWN BY: DATE: S.A.S. 2/25/99 DESIGNED BY: 0003 ± .015 CHECKED BY: 0003 ± .015 APPROVED BY: 0003 ± .015 C.V. R.V.		TITLE: SM98007 2 AXIS INSTALLATION DRAWING		
REVISIONS:		C.E.S. 01 J.A.K. ± .005		SCALE: 1:1 FILE: A9807-1035-000RA.DWG		
KEY / CONFIGURATION CODE NUMBER:		PART NUMBER:		A		

















Omega Series Digital PWM Brushless Servo Amplifiers

- PWM (Pulse-Width-Modulated) Brushless servo amplifiers to 20KW

Analog Brush Type Servo Amplifiers

- Linear Brush type servo amplifiers to 2.6KW
- PWM (Pulse-Width-Modulated) Brush type servo amplifiers to 28KW

Analog Brushless Servo Amplifiers

- Linear Brushless servo amplifiers to 3.5KW
- PWM (Pulse-Width-Modulated) Brushless servo amplifiers to 51KW

Permanent Magnet DC Brush Type Servo Motors

- Continuous Torques to 335 in. lb.
- Peak Torques to 2100 in. lb.

Permanent Magnet DC Brushless Servo Motors

- Continuous Torques to 1100 in. lb.
- Peak Torques to 2200 in. lb.



GLENTEK

"Solutions for Motion Control"

MANUAL#: 9015-3040-000
REVISION: (C)
DATE: 19 July 2004

208 Standard Street, El Segundo, California 90245, USA.
Telephone: (310) 322-3026; Fax: (310) 322-7709
www.glentek.com e-mail sales@glentek.com

