


OPERATION & SERVICE MANUAL

Model SMA8715

Brushless Type Amplifier System



GLENTEK

"Solutions for Motion Control"

NOTES

TABLE OF CONTENTS

INTRODUCTION.....	5
CHAPTER ONE: DESCRIPTION, FEATURES AND SPECIFICATIONS	
1.1 Description	6
1.1.1 Standard Encoder to Sine Mode	6
1.1.2 Twang Mode.....	6
1.2 Features.....	6
1.2.1 Single Amplifier Module (SMA8715-1).....	6
1.2.2 Stand Alone One Axis Amplifier (SMA8715-1A-1)	7
1.2.3 Multi-Axis Power Supply	7
1.3 Specifications	8
1.3.1 Single Amplifier Module (SMA8715-1).....	8
1.3.1.1 Input and Output Power	8
1.3.1.2 Signal Inputs.....	8
1.3.1.3 Digital Inputs.....	8
1.3.1.4 System	8
1.3.1.5 Outputs.....	8
1.3.2 Stand Alone One Axis Amplifier (SMA8715-1A-1)	9
1.3.3 Multi-Axis Power Supply	9
1.3.3.1 Input and Output Power	9
1.3.4 Mechanical	9
CHAPTER TWO: THEORY OF OPERATION	
2.1 Current Mode vs Velocity Mode	10
2.2 Protection Circuit	10
CHAPTER THREE: MODEL NUMBERING	
3.1 Introduction	11
3.2 Single Module	11
3.3 Multi Axis Amplifier.....	12
3.4 Stand Alone Amplifier	12
CHAPTER FOUR: INSTALLATION PROCEDURE	
4.1 Introduction.....	13
4.2 Mounting	13
4.3 Wiring.....	13
4.3.1 RFI/EMI and Wiring Technique	13
4.3.2 Wire Size and Type	13
4.3.3 Connector Size and Type.....	14
4.3.3.1 The Power Connector of the Single Amplifier Modules	14
4.3.3.2 The Signal Connector	14
4.3.3.3 The Power and Motor Connector of the Stand Alone Amplifier	14
4.4 Single Amplifier Module Connections(SMA8715-1)	15
4.4.1 Buss and Motor Connections - J2	15
4.4.2 Signal Connections for the Encoder to Sine Mode Amplifier - J1	15
4.4.3 Signal Connections for the Encoder to Sine Mode Pre-amp	16
4.5 Stand Alone Amplifier Connectins (SMA8715-1A-1)	16
4.5.1 Motor Connections - J2.....	16
4.5.2 Power Connections - J6.....	16
4.6 Multi Axis Power Supply Connections.....	17
CHAPTER FIVE: START UP AND ADJUSTMENT PROCEDURE	
5.1 Introduction.....	18
5.2 Logic Input Configuration.....	18
5.3 Encoder to Sine Mode Amplifier Configuration	18
5.3.1 +15V/+5V Logic Level Configuration	18

5.3.2	Standard Configuration for Encoder to Sine Velocity Mode and Current Mode...	19
5.3.3	Tach Lead	19
5.3.4	Tach - Reverse Configuration	19
5.3.5	Motor - Reverse Configuration	19
5.3.6	Coarse Balance	19
5.3.7	Hall 60/120	19
5.3.8	Encoder - Reverse Configuration	19
5.3.9	Rotary Motor (S3) Settings.....	20
5.3.10	Linear Motor (S3) Settings	20
5.3.11	Trap Only - Forced Hall	20
5.3.12	Range	20
5.3.13	Encoder Configuration	20

CHAPTER SIX: START UP AND CALIBRATION

6.1	Introduction	22
6.2	Initial Start Up	22
6.3	Phasing Procedures.....	22
6.4	Encoder to Sine Mode Amplifier Calibration	23
6.4.1	Encoder to Sine Mode Amplifier Calibration Procedure - Velocity Mode	23
6.4.2	Encoder to Sine Mode Amplifier Calibration Procedure - Current Mode	23
6.5	Calibration Setup Record	25

CHAPTER SEVEN: MAINTENANCE, REPAIR AND WARRANTY

7.1	Maintenance	26
7.2	Amplifier Faults	26
7.2.1	Table of Fault LED Conditions	26
7.2.2	Under Voltage Fault.....	26
7.2.3	Motor Over Temp Fault.....	26
7.2.4	High Speed Electronic Circuit Breaker (HS/ECB) Fault.....	27
7.2.5	Low-Speed Electronic Circuit Breaker (LS/ECB) Fault.....	27
7.2.6	Over Temp Fault.....	27
7.2.7	Over Voltage Fault.....	27
7.2.8	Hall Error Fault	27
7.2.9	Resetting A Fault	27
7.3	Amplifier Failure	27
7.4	Factory Repair	28
7.5	Warranty	28

APPENDIX A: AMPLIFIER DRAWINGS

SMA8015 Brushless Power Board Installation Schematic (8715-1030)	30
SMA8015 Brushless Power Board Assembly Drawing (8715-1031)	31

SMA8715-1 Encoder to Sine Single Amplifier Module Installation (8015-1056)	33
SMA8715-1A-1 Encoder to Sine Stand Alone Amplifier Installation(8015-1058).....	34
SMA8X15-2A-2 2-axis Installation Drawing (8000-1833).....	35
SMA8X15-4A-4 4-axis Installation Drawing (8000-1835).....	36
SMA8X15-6A-6 6-axis Installation Drawing (8000-1837).....	37
GP8600-2030 30A Power Supply Assembly Drawing (8600-2030).....	38
GP8600-2031 60A Power Supply Assembly Drawing (8600-2031).....	39

APPENDIX B: PERSONALITY MODULE (PRE-AMP)

SMA8715 Encoder to Sine Mode Installation Schematic (8000-2432)(Early Version).41
SMA8715 Encoder to Sine Mode Assembly Drawing (8000-2430)(Early Version).....43
SMA8715 Encoder to Sine Mode Installation Schematic (8000-2432)(Later Version).44
SMA8715 Encoder to Sine Mode Assembly Drawing (8000-2430)(Later Version).....46

APPENDIX C: EUROPEAN UNION EMC DIRECTIVES

Electromagnetic Compatibility Guidelines For Machine Design..... 48

CE Certification..... 53

INTRODUCTION

Glentek's brushless DC motors and amplifiers offer the ultimate in low maintenance and high performance motion-control. Glentek offers a full line of matched motors and amplifiers to meet virtually every motion-control application.

This manual provides all the technical information necessary to install, configure, operate, and maintain our TORQUE-SWITCH™ series, brushless servo-motor amplifiers, model SMA8715 and the high power version: SMA8715HP.

We suggest that you take the time to read this manual from cover-to-cover before attempting to work with these amplifiers for the first time. If at any time you have questions not addressed in this manual, or have any special requirements, please feel free to call and discuss them with a Glentek applications engineer. We are happy to provide both off-the-shelf and custom products. With over three decades in the servo-motor/amplifier business, we have a vast pool of applications knowledge waiting to assist you.

Thank you for selecting Glentek for your motion-control needs. It is our goal to save you time and money, and to provide you with a superior product.

CHAPTER ONE: DESCRIPTION, FEATURES AND SPECIFICATIONS

1.1 Description:

This brushless amplifier system has been designed to offer you, our customer, a large degree of flexibility and customization with a standard, in stock product. Each amplifier module consists of a standard power output board with a personality module mounted on it. Following is a brief description of this personality module and its mode(s) of operation:

1.1.1 Standard Encoder to Sine Mode (SMA8715/SMA8715HP) -

In this mode of operation, the brushless motor is commutated by hall sensors and an encoder, or an encoder which contains three commutation signals (comm. tracks). This personality module can be configured for the following two different types of operation:

VELOCITY MODE - In this mode of operation, the personality module generates a tachometer signal which is used to close a velocity loop in the amplifier.

CURRENT MODE - In this mode of operation, which is also commonly referred to as torque mode, a current in the motor is produced which is directly proportional to the input signal.

1.1.2 Twang Mode (SM8715/SMA8715HP) - I

In this mode of operation, the brushless motor is commutated by an encoder only.

These brushless amplifiers come with all industry standard inputs such as "limit, fault output, etc. They are available in the following types of configurations:

As amplifier modules where you supply the DC Buss voltage, cooling fan(s), fusing and shunt regulator. Please see section 1.2.1 for more detailed information.

As a stand alone one axis amplifier, SMA8715-1A-1, which contains a DC power supply, cooling fan, fusing and shunt regulator. Please see section 1.2.2 for more detailed information.

For multi-axis applications, the multi-axis baseplate power supply can supply DC power, cooling fans, zero crossing solid state relays, fusing and a shunt regulator for up to 6 axis or 60 amperes continuous. Please see section 1.2.3 for more detailed information.

1.2 Features:

1.2.1 Single Amplifier Module (SMA8715-1):

- Ergonomic design: Easy access to connections, adjustments, and test points.
- Wide operating buss voltage: 70-340 VDC.
- Complete isolation: Complete isolation from input to output.
- Dual signal inputs: Two single-ended or one differential. Both single-ended inputs may be used simultaneously. All inputs have up to 15,000 A/V gain, and all inputs will accept +/-13VDC.
- Dual mode operation: The standard amplifier may be configured for velocity (RPM) control or current (torque) control.
- Current limit: Maximum motor current is adjustable.
- Silent operation: Carrier frequency is 20KHz.
- Short circuit protection: Complete short circuit and ground fault protection.
- LED diagnostics: Red LED(S) illuminate to display various fault conditions and a green LED illuminates to indicate normal operating conditions.

- Frequency response: (Velocity Loop) 750 Hz minimum.
- Frequency response: (Current Loop) 2 KHz minimum.
- Digital limit/enable Inputs: Three separate logic inputs can stop the motor in either or both directions. Inputs may be configured for active-high or active-low, pull-up or pull-down termination, and a 0 to +5V or 0 to +15V range.
- Tachometer output: DC output proportional to motor RPM.
- Fault input/output: Open-collector output goes low in the event of a fault. This input is configured so that externally forcing this output low will inhibit the amplifier. This allows all fault outputs in a multi-axis system to be connected together (wire-ORed) to shut down all amplifiers should any amplifier have a fault.
- Manual and external fault reset: Push button and a separate input is provided to reset the amplifier after a fault.
- High-Speed Electronic Circuit Breaker (HS/ECB): Instantly shuts down the amplifier in the event of a short across the motor leads or a ground fault condition. (i.e. amplifier exceeds 80A for 10 microseconds)
- Low-Speed Electronic Circuit Breaker (LS/ECB): Shuts down the amplifier if the amplifier is operated above the maximum continuous current rating (i.e. 15A for standard 120VAC, 10A for standard 240VAC; 20A for High Power 120VAC and 15A for High Power 240VAC) for a pre-determined period (i.e. 3 seconds).
- Over/under voltage and over temperature: These circuits constantly monitor the amplifier power-supply voltages, and the amplifier-heatsink temperatures. They will shut down the amplifier in the event of any out-of-specification condition. (The overvoltage protection circuit is set to turn on at +250VDC for 120VAC line input and +450VDC for 240VAC line input.)
- Multi-axis chassis: Up to six amplifier modules may be mounted on a single baseplate. Multi-axis baseplates include a DC power supply, cooling fan(s) and wiring for each respective amplifier module.

1.2.2 Stand Alone One Axis Amplifier (SMA8715-1A-1):

The stand alone amplifier has all the features that the Single Amplifier Module (section 1.2.1) have, plus the following additional features:

Line operated AC power operation: Fused AC input for single or three phase input with in-rush current protection at turn-on. No power isolation transformer is required.

Fused regen clamp circuit (shunt regulator) with LED indicator and 50W internal load resistor bank bleeds off excess DC Buss voltage when decelerating a large load inertia. The regen clamp circuit is set to turn on at +215VDC for 120VAC operation and +400VDC for 240VAC operation.

All faults can be monitored through isolated logic signals.

1.2.3 Multi-Axis Power Supply (GP8600-203X):

Power supply for 2 to 6 axis amplifier baseplate.

Line operated AC power operation: Fused AC input for single or three phase inputs with a solid state zero-crossing switch which limits in-rush current at turn-on. No power isolation transformer is required.

Fused regen circuit (shunt regulator) with LED indicator and 300W internal load resistor bank bleeds off excess DC Buss voltage when decelerating a large load inertia. Additional regen resistor can be connected externally.

Bridge rectifier(s) and filter capacitor.

Power turn on in-rush limiter (solid state zero crossing switch).

Cooling fans.

1.3 Specifications:

This section contains the specifications for the brushless encoder to sine mode servo amplifiers. These specifications also include power supplies for the amplifiers.

NOTE: All data in this section is based on the following ambient conditions: 120 °F (50 °C) maximum. Forced air cooling.

1.3.1 Single Amplifier Module (SMA8715-1):

The amplifier module(s) require an external DC power supply which must include a bridge rectifier, buss capacitor, solid-state relay and shunt regulator. Forced air cooling is required to meet the maximum power ratings specified below.

1.3.1.1 Input and Output Power:

Input Power/ Buss Voltage(B+)	Output Power (current)			
	Standard		High Power	
	R.M.S.	Peak	R.M.S.	Peak
120VAC/170VDC	15A	25A	20A	40A
240VAC/340VDC	10A	25A	15A	35A

1.3.1.2 Signal Inputs:

Amplifier Model	Signal Input	Maximum Voltage	Minimum Impedance	Velocity Gain Amp./Volt	Current Gain Amp./Volt
8715	Differential	13	10,000	15,000(min.)	0-5
8715	Single-ended	±13	10,000	15,000(min.)	0-5

1.3.1.3 Digital Inputs:

± Limit, Inhibit & Reset: -0.5 to +40 Volts max. Terminated by 10KΩ.

Fault (as input): -0.5 to +40 Volts max. Terminated by 10KΩ.

Typical for all digital inputs: Digital inputs have hysteresis with thresholds at 1/3 and 2/3 of +5V or +15V depending on range select jumper.

1.3.1.4 System:

Drift offset over temperature reference to input: 0.01mV/ °C max.

Frequency response (Velocity loop): 750Hz min.

Frequency response (Current loop): 2KHz min.

Dead band: None.

Form factor: 1.01.

1.3.1.5 Outputs:

Fault (as output): Active low. Open-collector output can sink 500mA max.

Abs. motor current: 10A/V.

Tachometer : 1000 source impedance, a high input impedance meter must be used (1milliohm/volt).

1.3.2 Stand Alone One Axis Amplifier (SMA8715-1A-1):

The stand alone one axis amplifier contains a single amplifier module, a DC power supply, a cooling fan, fusing and shunt regulator in a sheet metal enclosure. It has the same specifications as the single amplifier module, refer to 1.3.1, except the DC power supply and cooling fan are included. The shunt regulator within the DC power supply has a 50W internal load resistor bank which bleeds off excess DC Buss voltage when decelerating a large load inertia. (Consult with factory).

NOTE: Customer must specify the input AC voltage(110-130VAC/208-240VAC) and the number of input phases (Single or Three Phase) when ordering (see chapter 3: model numbering), so that the proper fan and power supply can be installed.

1.3.3 Multi Axis Power Supply:

The multi-axis power supply contains all items listed under 1.2.3. Note: If you do not need the shunt regulator and or solid state zero crossing switch, please specify at time of order as these items can be deleted which will in-turn decrease the cost of the unit accordingly.

1.3.3.1 Input and Output Power:

Input Power (Buss, B+, Control Power, Fans): 120/240VAC.

Buss Voltage, B+: 170/340VDC.

Output Power: 30/60A continuous.

1.3.4 Mechanical:

Model	L x W x H (inches)	Weight (lbs)
SMA8715-1(Single Amplifier Module)	7.125 x 1.38 x 4.53	1.28
SMA8715-1A-1 (Stand Alone Amplifier)	9.025 x 4.00 x 5.66	5.25
SMA8715-2A-2 (2 Axis Amplifier System)	9.00 x 10.50 x 7.70	9.36
SMA8715-4A-4 (4 Axis Amplifier System)	13.00 x 10.50 x 7.70	15.12
SMA8715-6A-6 (6 Axis Amplifier System)	16.50 x 10.50 x 7.70	19.90

CHAPTER TWO: THEORY OF OPERATION

2.1 Current Mode vs Velocity Mode:

The fundamental difference between current mode and velocity mode is that in current mode, an external command signal controls the torque of the motor, rather than the velocity. In velocity mode, an external command signal controls the velocity (RPM) of the motor, rather than the torque. In a current mode amplifier, the command signal is proportional to the motor current, thus it is also proportional to the torque of the motor. In a velocity mode amplifier, the current loop amplifier stage is preceded by a high gain error amplifier which compares the command signal and the tachometer feedback signal.

Current mode amplifiers are usually used in Position Control Systems where no tachometer feedback is required. While velocity mode amplifiers are usually used in Classic Cascaded Control Systems where there are position, velocity and current loops in the system. Velocity loops tend to have a higher bandwidth and operate better near zero speed.

2.2 Protection Circuit:

The High-Speed and Low-Speed Electronic Circuit Breakers (HS/ECB and LS/ECB) protect the amplifier and motor from being damaged by high motor current (specified max. peak and rms current values). The Over Temperature and Over Voltage detection circuits will shut off the amplifier when the temperature of the amplifier or the buss (B+) voltage exceeds a specified limit. Also, there are circuits which limit the motor from running in either or both directions.

CHAPTER THREE: MODEL NUMBERING

3.1 Introduction:

This chapter contains the model numbering system for the SMA8715 single module, multi axis, and stand alone amplifiers. The model numbering system is designed so that you will be able to create the correct model number of the amplifier needed.


When placing an order for the SMA8715 amplifier system please contact Glentek sales dept. and have the following information available:

1. Type of motor you will be using and motor specs.
2. Pole pitch of the motor; if linear motor, electrical cycle (The distance from one North magnet to the other North magnet, or South to South). If rotary motor, number of poles.
3. The encoder resolution of your system.
 - Rotary - Pulses per revolution.
 - Linear - Linear distance between encoder pulses.It is important that encoder resolution be for a single channel, not for two channels operating in quadrature.
4. Machine power voltage available at site i.e. 3-phase, 208.
5. The phase-to-phase inductance of the motor.
6. The maximum speed for motor.
7. BEMF voltage of motor.
8. Max. continuous and max. peak current required at motor.
9. Amplifier mode of operation, current mode or velocity mode.
10. If known, types of inhibit, limits, and reset. If not specified, amplifier will be shipped with type "A" inhibit, limits and reset.
11. Input option will be set single-ended. It may be set differential, although Glentek recommends a single-ended input whenever possible.


From the above information the Glentek representative will issue a Custom Configuration Code for your specific application.

Note: Whenever possible, it is very desirable to have the motor sent to Glentek for initial system checkout at the factory, this tends to eliminate many field problems.


3.2 Single Module Amplifier:



3.2 Multi Axis Amplifier:



3.4 Stand Alone Ampifer:



CHAPTER FOUR: INSTALLATION

4.1 Introduction:

This chapter provides information for connecting amplifiers to your system. If you need additional help, contact a Glentek applications engineer.

4.2 Mounting:

Appendix A contains all the wiring diagrams, assembly drawings, and mechanical information necessary to install the amplifiers. The amplifier package should be mounted in a clean, dry enclosure, free of dust, oil, or other contaminants.

**NEVER INSTALL THE AMPLIFIER PACKAGE IN ANY LOCATION WHERE
FLAMMABLE OR EXPLOSIVE VAPORS ARE PRESENT.**

IMPORTANT: Muffin fan(s) are mounted along one edge of the baseplate to provide cooling. At least 3 inches must be allowed between the fan side and the side opposite the fans and any other surface. The clearance to any other side of the amplifier package is not critical, although sufficient space should be allowed for easy wiring and servicing.

4.3 Wiring:

4.3.1 RFI/EMI and Wiring Technique:

IMPORTANT: All PWM equipment inherently generates radio-frequency interference (RFI), and wiring acts as antennae to transmit this interference. In addition, motors inherently generate electromagnetic interference (EMI). Unless the wiring is very short, some sort of shielding on the motor wires is necessary to meet FCC RFI/EMI guidelines and to protect other equipment from the effects of RFI/EMI. We recommend that shielded wire be used, or the wires should be run in metallic conduit. The shield or conduit should be connected to the amplifier baseplate, which in turn must be earth grounded. In addition, a conductor of the same gauge as the motor wires must be connected from the motor case to the amplifier baseplate to provide protection from shock hazard. The earth grounding is necessary to meet National Electrical Code (NEC) requirements as well as suppressing RFI/EMI.

Additional RFI suppression may be obtained by placing inductors in each motor lead near the amplifier. Consult a Glentek applications engineer for inductor recommendations. Glentek stocks a complete line of inductors for virtually every application.

IMPORTANT: The signal wiring to hall-sensors and encoder, and the signal inputs to the amplifier are susceptible to noise pickup. Excessive noise pickup will cause erratic amplifier operation. We urge that each signal input be run in a twisted-pair, shielded cable. The hall-sensor signal lines and the encoder signal lines should be run in a three twisted-pair, shielded cable. In each case the shield should be terminated at the amplifier end only to a common terminal. We also recommend that the signal lines be kept as far as possible from any power or motor wires.

4.3.2 Wire Size and Type:

IMPORTANT: To ensure safe operation, Glentek strongly recommends that all wiring conform to all local and national codes.

Recommended Wire Size and Type:

Motor Wires:	14AWG, shielded - Standard. 12AWG, shielded High Power.
Motor Case Ground:	Same as motor wires, or use metallic conduit.
Main Power:	Same as motor wires.
Signal Input:	22AWG, twisted-pair, shielded.
Logic Inputs/Outputs:	22AWG, shielded with its return lead.
External Tachometer:	22AWG, twisted-pair, shielded.
Hall Sensors :	22AWG, three twisted-pairs, over-all shielded.
Encoder :	22AWG, three twisted-pairs, over-all shielded.

4.3.3 Connector Size and Type:

4.3.3.1 The Power Connector of the Single Amplifier Modules - J2 of the Main Amplifier:

All amplifiers are shipped with the right angle AUGAT terminal block mounted as it power connector. The vertical angle AUGAT terminal block and the PHOENIX connector are two options one can choose to use for the power connector. The specifications of these connectors are listed as follow:

- AUGAT® RDI 6 Series Tri-Barrier Terminal Blocks (PART# 6PCR-05) - **Default**:
Screw Size/Spacing: 6 (#6-32 on .375" centers).
Terminal Style: PC (Printed Circuit Pin).
Terminal Orientation: R (**Right Angle**).
Number of Screw Terminals: 05 (5 screw positions).
Terminal lugs: Thomas & Betts (PART# A116 for 18AWG wire, PART# B19 for 14AWG wire and PART# C133 for 12/10AWG wire).
- AUGAT® RDI 6 Series Tri-Barrier Terminal Blocks (PART# 6PCV-05):
Screw Size/Spacing: 6 (#6-32 on .375" centers).
Terminal Style: PC (Printed Circuit Pin).
Terminal Orientation: V (**Vertical Angle**).
Number of Screw Terminals: 05 (5 screw positions).
Terminal lugs: Thomas & Betts (PART# A116 for 18AWG wire, PART# B19 for 14AWG wire and PART# C133 for 12/10AWG wire).
- PHOENIX CONTACT, COMBICON Headers and Plugs with 7.62mm pitch
(Header P/N: GMSTBA 2,5/5-G-7,62, Plug P/N: GMSTB 2,5/5-ST-7,62):
Header with side panels, plug-in direction parallel to PCB.
5 positions.
Color: green.

4.3.3.2 The Signal Connector:

The signal connectors are supported by the molex® KK .100" (2,54mm) Centerline Connector System.

- J1 of the Main Amplifier:
Mating Connector: molex® 2695 Series .100 (2.54mm) Center Crimp Terminal Housing(P/N: 22-01-3175): red nylon housing.
15 positions.
with polarizing rib.
- J4 and J5 of the Encoder to Sine Pre-amp:
Mating connector for J4: molex® 2695 Series (P/N: 22-01-30107).
Mating connector for J5: molex® 2695 Series (P/N: 22-01-3067).
Crimp Terminals for the above mating connector: molex® Crimp Terminals (P/N: 08-55-0102):
15 microinch select gold plated.brass.

4.3.3.3 The Power and Motor Connector of the Stand Alone Amplifier:

- Motor - J2 of the Stand Alone Amplifier:
Mating Connector: PHOENIX CONTACT, COMBICON Plugs in 7.62mm Pitch
(P/N: GMVSTBR 2.5/3-ST-7.62): with vertical plug-in direction to the conductor axis.
3 positions.
Color: green.
- Power Input - J6 of the Stand Alone Amplifier:
Mating Connector: PHOENIX CONTACT, COMBICON Plugs in 7.62mm Pitch (P/N: GMVSTBW 2.5/4-ST-7.62):
with vertical plug-in direction to the conductor axis.
4 positions.
Color: green.

4.4 Single Amplifier Module Connections(SMA8715-1):

4.4.1 Buss and Motor Connections - J2:

Signal Name	Terminal	Notes
B -	J2-1	DC Buss -
B +	J2-2	DC Buss+
MOTOR T	J2-3	Phase T of the motor.
MOTOR S	J2-4	Phase S of the motor.
MOTOR R	J2-5	Phase R of the motor.

4.4.2 Signal Connections for the Encoder to Sine Mode Amplifier - J1:

Signal Name	SMA8715 Terminal	Notes
SIGNAL 1+	J1-1	Differential signal input.
SIGNAL 1-	J1-2	Differential signal return.
SIGNAL 2+	J1-3	Single-ended signal 2 in.
COMMON	J1-4	Signal common.
MODE 1	J1-5	Factory use only
COMMON	J1-6	Common.
ABS. I	J1-7	Absolute value of the motor current (10A/V)
LIMIT +	J1-8	Inhibits the motor in + direction.
LIMIT -	J1-9	Inhibits the motor in - direction.
INHIBIT	J1-10	Inhibits the motor in both directions.
FAULT	J1-11	Goes low for a fault, or inhibits the amplifier when forced low.
COMMON	J1-12	Digital common.
RESET IN	J1-13	Resets fault latch.
MTR TEMP	J1-14	Motor over temperature switch input.
MODE 2	J1-15	Factory use only

4.4.3 Signal connections for the Encoder to Sine Mode Pre-amp:

Signal Name	Terminal	Notes
Encoder Input (J4):		
N/C	J4-1	No Connection
A	J4-2	Phase A signal input.
A*	J4-3	Negative phase A signal input.
B	J4-4	Phase B signal input.
B*	J4-5	Negative phase B signal input.
Z	J4-6	Phase Z signal input.
Z*	J4-7	Negative phase Z signal input
COM	J4-8	Common for Encoder.
COM	J4-9	Common for Encoder.
COM	J4-10	Common for Encoder.
Hall Sensor Input (J5):		
+V	J5-1	+VDC for Hall Effect Sensors
HALL 1	J5-2	Hall Sensor 1. Check motor data for phasing
HALL 2	J5-3	Hall Sensor 2. Check motor data for phasing
HALL 3	J5-4	Hall Sensor 3. Check motor data for phasing
COM	J5-5	Common for Hall Sensors
COM	J5-6	Common for Hall Sensors

4.5 Stand Alone Amplifier Connections (SMA8715-1A-1):

The Stand Alone Amplifier has the same signal connections as the Single Amplifier Module. The Power and Motor connections are as follows:

4.5.1 Motor Connections - J2:

Signal Name	Terminal	Notes
MOTOR T	J2-1	Motor phase T
MOTOR S	J2-2	Motor phase S
MOTOR R	J2-3	Motor phase R

4.5.2 Power Connections - J6:

Signal Name	Terminal	Notes
GND	J6-1	Chassis ground.
AC	J6-2	AC power input. (Omit for single-phase input)
AC	J6-3	AC power input.
AC	J6-4	AC power input.

4.6 Multi Axis Power Supply Connections:

Connector TB201 is shown in the following drawings: 8000-1833 for 2-axis baseplate, 8000-1835 for 4-axis baseplate and 8000-1837 for 6-axis baseplate. Fuse Block FB301 is shown in drawings 8600-2030 and 8600-2031. All of the above drawings are in Appendix A.

Signal Name	Terminal	Notes
AC - FAN	TB201 on baseplate.	AC fan power input.
AC - FAN	TB201 on baseplate.	AC fan power input.
AC - MAIN	FB301 on Power Supply Sub-assembly	AC main power input.
AC - MAIN	FB301 on Power Supply Sub-assembly	AC main power input.
AC - MAIN	FB301 on Power Supply Sub-assembly	AC main power input.

CHAPTER FIVE: CONFIGURATION

5.1 Introduction:

Each amplifier has several configuration options. This chapter describes these options and how to implement them. If desired, Glentek will be happy to pre-configure your amplifiers.

NOTE: Each amplifier module or stand alone amplifier is configured and shipped according to the model number (instructions to construct a model number is in chapter three) when the order is placed. It is important for the user to realize that any adjustment on the dip-switches or jumpers by the user will result in discrepancies between the model number and the actual configuration of the amplifier.

NOTE: Earlier versions of this Personality Boards use dip switches while the newer versions use micro shunt jumpers. "ON" is the dip switch in the "ON" position or the micro shunt is installed. "OFF" is the dip switch in the off position or the micro shunt not installed. In the table below, SX-X identifies a switch location on earlier boards and JPX-X identifies a jumper location on later boards.

5.2 Logic Input Configuration:

There are five logic inputs: Limit +, Limit -, Inhibit, Reset In, Motor Temp. The first four may be configured for active-high or active-low signals, and pulled-up or pulled-down termination (type A, B, C, and D). The motor-temp may be configured for active-high or active-low signals, and is always pulled-up (type A, and C). All five logic inputs have a selectable 0 to +5VDC or 0 to +15VDC range.

Type "A": Requires grounding of input to disable the amplifier (pull-up, active-low).

Type "B": Requires a positive voltage at input to disable the amplifier (pull-down, active-high).

Type "C": Requires grounding of input to enable the amplifier (pull-up, active-high).

Type "D": Requires a positive voltage at input to enable the amplifier (pull-down, active-low).

5.3 Encoder to Sine Mode Amplifier Configuration:

The following table shows the dip switches that need to be configured for the Type A, B, C, and D configurations. The standard configuration is shown in **bold**.

	Type A	Type B	Type C	Type D
LIMIT±	S2-8/JP7-3 - OFF S2-5/JP10-4 - ON	S2-8/JP7-3 - ON S2-5/JP10-4 - OFF	S2-8/JP7-3 - OFF S2-5/JP10-4 - OFF	S2-8/JP7-3 - ON S2-5/JP10-4 - ON
INHIBIT	S2-7/JP7-2 - OFF S2-4/JP10-3 - ON	S2-7/JP7-2 - ON S2-4/JP10-3 - OFF	S2-7/JP7-2 - OFF S2-4/JP10-3 - OFF	S2-7/JP7-2 - ON S2-4/JP10-3 - ON
RESET IN	S2-6/JP7-1 - OFF S2-3/JP10-2 - ON	S2-6/JP7-1 - ON S2-3/JP10-2 - OFF	S2-6/JP7-1 - OFF S2-3/JP10-2 - OFF	S2-6/JP7-1 - ON S2-3/JP10-2 - ON
MTR TEMP	S2-2/JP10-1 - ON	not available	S2-2/JP10-1 - OFF	not available
FAULT	standard	not available	not available	not available

5.3.1 +15V/+5V Logic Level Configuration (Default: S2-1/JP8=OFF):

Select pullup voltage.

+15V: S2-1/JP8 = OFF.

+5V: S2-1/JP8 = ON.

5.3.2 Standard Configuration for Encoder to Sine Velocity Mode and Current Mode:

Dip Switch Or Jumper S1/JP	Name	Velocity Mode	Current Mode
S1-8/JP4	CURRENT MODE	OFF	ON
S1-7/JP2	VELOCITY MODE	ON	OFF
S1-6/JP3	TACH LEAD	OFF	OFF
S1-5/JP6-3	TACH REVERSE	ON	ON
S1-4/JP5	MTR REVERSE	OFF	OFF
S1-3/JP1	COARSE BALANCE	OFF	OFF
S1-2/JP6-2	HALL 60/120	OFF	OFF
S1-1/JP6-1	ENCODER REVERSE	OFF	OFF

5.3.3 Tach Lead (Default: S1-6/JP3=OFF):

The tach lead switch is turned ON to add capacitance to the tach lead circuit. This may be needed if you have a large one hook overshoot when monitoring tach out. This switch should remain off unless instructed to turn on by a Glentek engineer.

5.3.4 Tach - Reverse Configuration (Default: S1-5/JP6-3=ON):

The tachometer reverse switch reverses the polarity of the tach feedback signal. Use it to solve motor runaway problems in velocity mode applications.

5.3.5 Motor- Reverse Configuration (Default: S1-4/JP5=OFF):

The motor reverse switch reverses the spinning direction of the motor for both current and velocity mode. It can also solve motor runaway problems in manner similar to the tach reverse switch.

5.3.6 Coarse Balance (Default: S1-3/JP1=OFF):

Occasionally it is necessary to turn the coarse balance switch ON to extend the range of the balance pot due to various offsets in the external signal. Useful for current mode applications.

5.3.7 Hall 60/120 (Default: S1-2/JP6-2=OFF):

There are four standard sensor configurations: 60°, 120°, 240°, and 300°. The 60°/300°, and 120°/240° sensor spacing are identical except for the direction of motor rotation which results.

To configure the amplifiers for 60°/300° sensor configuration: S1-2/JP6-2 (ON).

To configure the amplifiers for 120°/240° sensor configuration: S1-2/JP6-2 (OFF).

5.3.8 Encoder- Reverse Configuration (Default: S1-1/JP6-1=OFF):

The encoder reverse switch is used as part of the phasing procedure. It is turned ON to switch the A and B encoder channels without physically switching the encoder leads.

5.3.9 Rotary Motor (S3/JP9) Settings:

Set switches based on motor poles and encoder resolution (before quadrature). Normally preset at factory.

Dip Switch Or Jumper S3/JP9	Name	(DEFAULT) SETTINGS
S3-1/JP9-1	Motor Poles / Encoder Count	See table below
S3-2/JP9-2	Motor Poles / Encoder Count	See table below
S3-3/JP9-3	Motor Poles / Encoder Count	See table below
S3-4/JP9-4	Motor Poles / Encoder Count	See table below
S3-5/JP9-5	Motor Poles / Encoder Count	See table below
S3-6/JP9-6	TACH PULSE WIDTH SETTING	FACTORY SET
S3-7/JP9-7	TACH PULSE WIDTH SETTING	FACTORY SET
S3-8/JP9-8	TACH PULSE WIDTH SETTING	FACTORY SET

Motor Pole / Encoder Count Switch / Jumper Setting Table						
POLES	ENCODER	S3-1/JP9-1	S3-2/JP9-2	S3-3/JP9-3	S3-4/JP9-4	S3-5/JP9-5
2	500	ON	ON	ON	OFF	ON
2	512	ON	ON	OFF	OFF	ON
2	625	OFF	ON	OFF	ON	ON
2	1000	OFF	ON	ON	OFF	ON
2	1024	OFF	ON	OFF	OFF	ON
2	1250	ON	OFF	OFF	ON	ON
2	2000	ON	OFF	ON	OFF	ON
2	2048	ON	OFF	OFF	OFF	ON
2	2500	OFF	OFF	OFF	ON	ON
2	4000	OFF	OFF	ON	OFF	ON
2	4096	OFF	OFF	OFF	OFF	ON
4	1000	ON	ON	ON	OFF	ON
4	1024	ON	ON	OFF	OFF	ON
4	1250	OFF	ON	OFF	ON	ON
4	2000	OFF	ON	ON	OFF	ON
4	2048	OFF	ON	OFF	OFF	ON
4	2500	ON	OFF	OFF	ON	ON
4	4000	ON	OFF	ON	OFF	ON
4	4096	ON	OFF	OFF	OFF	ON
4	5000	OFF	OFF	OFF	ON	ON
4	8000	OFF	OFF	ON	OFF	ON
4	8192	OFF	OFF	OFF	OFF	ON
6	500	ON	ON	ON	OFF	OFF
6	512	ON	ON	OFF	OFF	OFF
6	625	OFF	ON	OFF	ON	OFF
6	1000	OFF	ON	ON	OFF	OFF
6	1024	OFF	ON	OFF	OFF	OFF
6	1250	ON	OFF	OFF	ON	OFF
6	2000	ON	OFF	ON	OFF	OFF
6	2048	ON	OFF	OFF	OFF	OFF
6	2500	OFF	OFF	OFF	ON	OFF
6	4000	OFF	OFF	ON	OFF	OFF
6	4096	OFF	OFF	OFF	OFF	OFF
8	1250	ON	ON	OFF	ON	ON
8	2000	ON	ON	ON	OFF	ON

POLES	ENCODER	S3-1/JP9-1	S3-2/JP9-2	S3-3/JP9-3	S3-4/JP9-4	S3-5/JP9-5
8	2048	ON	ON	OFF	OFF	ON
8	2500	OFF	ON	OFF	ON	ON
8	4000	OFF	ON	ON	OFF	ON
8	4096	OFF	ON	OFF	OFF	ON
8	5000	ON	OFF	OFF	ON	ON
8	8000	ON	OFF	ON	OFF	ON
8	8192	ON	OFF	OFF	OFF	ON
8	10000	OFF	OFF	OFF	ON	ON
8	16000	OFF	OFF	ON	OFF	ON
8	16384	OFF	OFF	OFF	OFF	ON
12	625	ON	ON	OFF	ON	OFF
12	1000	ON	ON	ON	OFF	OFF
12	1024	ON	ON	OFF	OFF	OFF
12	1250	OFF	ON	OFF	ON	OFF
12	2000	OFF	ON	ON	OFF	OFF
12	2048	OFF	ON	OFF	OFF	OFF
12	2500	ON	OFF	OFF	ON	OFF
12	4000	ON	OFF	ON	OFF	OFF
12	4096	ON	OFF	OFF	OFF	OFF
12	5000	OFF	OFF	OFF	ON	OFF
12	8000	OFF	OFF	ON	OFF	OFF
12	8192	OFF	OFF	OFF	OFF	OFF
TRAP		X	X	ON	ON	ON
INDEX		X	X	ON	ON	OFF

5.3.10 Linear Motor (S3/JP9) Settings:

Linear motor applications are shipped preconfigured. Normally switches are OFF.

Dip Switch Or Jumper S3/JP9	Name	(DEFAULT) SETTINGS
S3-1/JP9-1	N/A	OFF
S3-2/JP9-2	TRAP ONLY (FORCED HALL)	OFF
S3-3/JP9-3	N/A	OFF
S3-4/JP9-4	N/A	OFF
S3-5/JP9-5	RANGE	OFF
S3-6/JP9-6	N/A	OFF
S3-7/JP9-7	N/A	OFF
S3-8/JP9-8	N/A	OFF

5.3.11 Trap Only - Forced Hall (Default: S3-2/JP9-2=OFF) :

The SMA8715 can be configured to run in Trap Mode. To do this, switch S3-2 ON for linear motor and S3-3, S3-4, S3-5 ON for rotary motor.

CHAPTER SIX: START UP AND CALIBRATION

6.1 Introduction:

This chapter contains the procedure required for initial start up and amplifier calibration. The SMA8715 can be configured to run in velocity mode or current mode operations.

Required Equipment: Oscilloscope, voltmeter & battery box. The battery box serves as a step input voltage command, applying and removing a flashlight battery can also be used for this function. Glentek sells a battery box BB-700 which is ideal for this function.

6.2 Initial Start Up:

When applying power to start up your amplifier system for the first time, we recommend you follow this procedure. If you have already gone through this procedure you can skip to the appropriate calibration procedure.

1. Check for any loose or damaged components.
2. Check that all connections are tight.
3. Be sure that the motor mechanism is clear of obstructions. If the mechanism has limited motion, e.g: a lead-screw, set the mechanism to mid-position.
4. Disconnect the signal and auxiliary inputs.
5. Be sure the Loop-Gain pot(s) are fully CCW.
6. Remove input fuses on the baseplate and apply main power. Check for the correct AC voltage at fuse block. The DC Bus (amplifier supply-voltage) will be 1.4 times this value. If voltage is correct, remove power and reinstall fuses.
7. Work on only one amplifier at a time.

6.3 Phasing Procedures




Figure 6.0 Three resistors of same value

1. Record dip-switch or jumper settings. (S3/JP9)
2. Using motor data, connect the Encoder and Hall Sensors to the amp. If using an encoder w/ commutation tracks, connect the encoder to the proper pinouts on J4 and the commutation tracks to the Hall Sensor connection at J5 (Hall 1 = Comm. track 1 etc.) See section 4.4.3 for more details. Also, connect +5 VDC to the encoder. Typically this can be found on the controller.
3. If using a separate encoder and hall sensors, connect the encoder to J4 and the hall sensors to J5. The power for the Hall Sensors is also located on J5. However, you also need to connect +5 VDC for the encoder from an external source (Typically the controller).
4. The encoder signals will also have to be "daisy chained" to the controller. Ensure that the encoder common from the motor is connected at both the amplifier and the controller. Ensure that the shield from the encoder cable is also connected at these points.
5. Connect the three motor leads to a resistor network as per figure 6.0. All three resistors should be the same value.
6. Place one scope probe on point B; connect ground of scope probe to point A. Remove cover from the amplifier. Connect 2nd scope probe to J1, pin 4 (phase R command) use J1-14 for scope ground. J1 is located on the main power board, on the left-hand side of the amp when viewing it from the front side (cover side). It is the only connector that has 14 pins. Pin 1 is at the top (Near fault LEDs).
7. Turn loop gain pot (RV7) on amplifier full Clockwise. Turn on B+ power and apply an analog input signal to either sig. 1 or sig. 2 on J1 of the amplifier. To do this, use a battery box, 1.5 VDC, 9 VDC battery, or analog offset signal from the controller.

8. Turn or slide motor. Compare the two sinewaves. Waveforms should be in phase or 180° out of phase. If sinewave is 180° out of phase, reversing motor direction will align it.
 9. If the waveforms are not in phase, move the scope probe from point B to point C. Repeat step 7. If is still not in phase, move scope probe to point D and repeat step 7. Repeat this process for J1-6 (S phase) and J1-8 (T phase), always rotating or sliding motor in the same direction. Make a note of which color motor lead aligns with which motor phase.(Example: Red = phase R etc.)
 10. Remove input signal and remove power from amplifier.
 11. Set the amp to "Trap Mode"; S3-2/JP9-2 ON for linear motor; S3-3/JP9-3, S3-4/JP9-3, S3-5/JP9-5 ON for rotary motor. (Refer to 5.3.13 for rotary, 5.3.10 for linear). Set scope probe back to J1-4 (phase R)
 12. Apply power and re-connect the input signal.
 13. Observe phasing as done earlier, now however, one waveform will be trapezoidal.
 14. If waveforms are not in phase, remove input signal, turn power off and change the hall sensor wires on J5 until they are in phase. (note: there are six possible combinations)
 15. Remove input signal and remove power from unit.
 16. Return dipswitches or jumpers to original position(s), as recorded on step #1.
 17. Connect motor leads to amplifier, R, S, T according to your notes.
 18. Proceed to step 6.4
- Note: All other axis or units that have the same wiring and components will be connected in the same manner. There is no need to repeat this procedure for every system or axis. Just use your notes from the above procedure to make connections.

6.4 Encoder to Sine Mode Amplifier Calibration:

The following pots will be set during calibration:

Note: RV7 is a single turn pot; RV1-RV6 and RV8-RV14 are 12-turn pots.

Note: RV8-RV14 are factory set and should not be adjusted. Adjusting these pots voids warranty.

Pots	Name of Port	Note
RV1	SIG 1 (Differential Input Signal Gain)	Sets the input voltage to RPM ratio, e.g. 10V=2000RPM (velocity mode) or input voltage to torque ratio, e.g. 10V=25A (current mode) required by your system for the differential input.
RV2	SIG 2 (Single-ended Input Signal Gain)	Same as Signal 1 input, except this is for single-ended input.
RV3	TACH (Tach Gain)	Used in conjunction with the compensation pot to set the system bandwidth. Not used in current mode. Shipped set at 100%. (full CW)
RV4	BAL (Balance)	Used to null any offsets in system.
RV5	COMP (Compensation)	Used in conjunction with the TACH pot to set the system bandwidth. Not used in current mode. Shipped set at full CW (minimum bandwidth).
RV6	I LIMIT (Current Limit)	Sets the maximum motor current. Shipped set at full CW (maximum current limit).
RV7	LOOP (Loop Gain)	Used to shut off uncalibrated amplifiers. When the loop gain is CCW, no current is delivered to the motor. Shipped set at full CCW.

6.4.1 Encoder to Sine Mode Amplifier Calibration Procedure - Velocity Mode:

The amplifier, in this configuration, receives an analog, bi-polar input command which is proportional to the required motor velocity.

1. Turn the Current Limit (R6) to mid position and the Loop Gain (RV7) full CCW.
2. Apply main power and fan power.
3. Slowly turn the Loop Gain (RV7) CW. The motor should be stopped or turning slowly. If the motor starts running away, turn Loop Gain pot(RV7) CCW, switch TACH REVERSE (S1-5/JP6-3) from OFF to ON (or vice versa) and retest. Leave the Loop Gain (RV7) full CW for all remaining adjustments.
4. Set the Balance (RV4) for zero motor rotation.
5. Connect the oscilloscope to ABS I (J1-7) and the battery box to Signal 2 Input. The voltage at J1-7 is a function of motor current: 1V=10A for SMA8715. While applying a step input voltage, adjust the

Current Limit (RV6) for the desired peak current. If the desired peak current cannot be achieved with the pot full CW, increase the input voltage or increase the Signal Gain (RV2).

The purpose of the following procedure is to set the system bandwidth to obtain a critically-damped response with the maximum possible tach gain. There are many possible settings of Tach Gain and Compensation which will yield a critically damped waveform. The optimum setting will occur when the Tach Gain is as CW as possible and the Compensation is as CCW as possible. However, the servo-loop may become unstable (the motor oscillates or hunts) with a very low (near CCW) setting of Compensation. In this case, stability is the limiting factor. At no time should the servo-loop be allowed to be unstable.

Amplifiers are normally shipped with the Tach Gain (RV3) set at 100%. This is a good place to start. If you are unsure of where the Tach Gain is set, turn the Tach Gain fully CW (up to 12 turns).

6. Move the oscilloscope to the TACH OUT (J3-C), set the battery box for a steady DC voltage and adjust the input voltage or Signal 2 gain for about 400RPM.
7. Pulse the input and compare the waveform with figure 6.1.
8. Adjust the Compensation pot CCW until the waveform is critically damped or one hook overshoot. Then proceed to step 10.
9. If the desired waveform cannot be obtained by adjusting the Compensation pot, back off (CCW) the Tach Gain pot a few turns and repeat step 8.
10. Do not adjust the Tach Gain or Compensation pots for the rest of the calibration procedure.
11. With the battery box still connected at J1-3 and J1-4 for single-ended input (or if your system uses the differential input, move battery box to J1-1 and J1-2), set battery box for a known DC voltage. Adjust Signal 2 Gain (RV2) or (RV1 for differential input) to obtain the desired motor velocity.
12. If the motor is rotating in the wrong direction for a given input polarity, turn the Loop Gain pot full CCW. Switch MTR REVERSE (S1-4/JP5) from OFF to ON (or vice-versa). Turn the Loop Gain pot back to full CW.
13. Remove the battery box, and repeat only step 4.
14. Calibration complete. Reconnect signal wires.




Figure 6.1 Critically damped, One Hook Overshoot, Under and Over damped waveforms

6.4.2 Encoder to Sine Mode Amplifier Calibration Procedure - Current Mode:

The amplifier in this configuration, receives an analog, bi-polar input command which is proportional to the required motor current (motor torque).

1. Turn the current limit (RV6) to mid position and the Loop Gain (RV7) full CCW.
2. Apply main power and fan power. Slowly turn the Loop Gain (RV7) full CW. Motor should be stopped or turning slowly.
3. Set Balance (RV4) for 0V at ABS I (J1-7).
4. Connect the oscilloscope to ABS I (J1-7), and the battery box to the Signal 2 Signal-ended Input (J1-3 and J1-4). The voltage on J1-7 is a function of motor current: 1V=10A. While pulsing a step input voltage, adjust the Current Limit for the desired peak current. If the desired peak current cannot be achieved with the pot full CW, increase the input voltage or increase the Signal 2 Gain (RV2).
5. With battery box still connected at J1-3 and J1-4 for single-ended input (or if your system uses the differential input, move battery box to J1-1 and J1-2), set battery box for a known DC voltage. Apply \pm input signal pulses and adjust the Signal 2 Gain pot (RV2) or (RV1 for differential input) to obtain the desired current gain of the amplifier.
6. If the motor is rotating in the wrong direction for a given input polarity, turn the Loop Gain pot full CCW. Switch MTR REVERSE (S1-4/JP5) from OFF to ON (or vice-versa). Turn the Loop Gain pot back to full CW.
7. Remove battery box, and repeat step 3.
8. Calibration complete. Reconnect signal wires.

6.5 Calibration Setup Record:

It is good practice to keep a record of all pot settings. Doing so will facilitate calibration on future units and repair on this unit. Although not a substitute for the calibration procedure, it will at least get you "in the ballpark." Remove the power and allow all capacitors to discharge before taking measurements. Note: The balance pot should not be measured in this fashion, set per step 4 in the calibration procedure.

Pot / Dip Switches / Jumpers	AMP1	AMP2	AMP3	AMP4	AMP5	AMP6
SIG. 1 J3-A to J3-G or H(Ω)						
SIG. 2 J3-B to J3-G or H(Ω)						
TACH J3-C to J3-G or H(Ω)						
COMP J3-D to J3-G or H (Ω)						
I LIMIT J3-E to J3-G or H (Ω)						
Signal input to Tach ratio: _V Signal / _V Tach						
LIMIT(PULL UP/DN) S2-8/JP7-3						
INHIBIT(PULL UP/DN) S2-7/JP7-2						
RESET(PULL UP/DN) S2-6/JP7-1						
LIMIT(ACTIVE HI/LOW) S2-5/JP10-4						
INHIBIT(ACTIVE HI/LOW) S2-4/JP10-3						
RESET(ACTIVE HI/LOW) S2-3/JP10-2						
MTR TEMP(ACTIVE HI/LOW) S2-2/JP10-1						
+15/+5 S2-1/JP8						

Date data taken: / / Serial number S/N: _____

Model number SMA _____

CHAPTER SEVEN: MAINTENANCE, REPAIR, AND WARRANTY

7.1 Maintenance:

Glentek amplifiers do not require any scheduled maintenance, although it is a good idea to occasionally check for dust build-up or other contamination.

7.2 Amplifier Faults:

If an amplifier should cease to operate and one or more of the fault LED's are lit, review the sections which follow on the fault in question for information and possible causes.

A FAULT CAN ONLY BE CAUSED BY ABNORMAL CONDITIONS. LOCATE AND CORRECT THE CAUSE OF THE FAULT BEFORE REPEATED RECYCLING OF POWER TO THE AMPLIFIER TO PREVENT POSSIBLE DAMAGE.

7.2.1 Table of Fault LED Conditions:

Input or Fault Condition	RUN LED	HS/ECB LED	LS/ECB LED	OVER VOLT LED	OVER TEMP LED	HALL ERROR LED	FAULT OUTPUT
Normal Operation	ON	OFF	OFF	OFF	OFF	OFF	NO
Limit + (ON)	ON	OFF	OFF	OFF	OFF	OFF	NO
Limit - (ON)	ON	OFF	OFF	OFF	OFF	OFF	NO
Inhibit (ON)	OFF	OFF	OFF	OFF	OFF	OFF	NO
Reset In (ON)	OFF	OFF	OFF	OFF	OFF	OFF	NO
Ext. Fault (ON)	OFF	OFF	OFF	OFF	OFF	OFF	YES
Undervoltage (+15V)	OFF	OFF	OFF	OFF	OFF	OFF	YES
HS/ECB (Latched)	OFF	ON	OFF	OFF	OFF	OFF	YES
LS/ECB (Latched)	OFF	OFF	ON	OFF	OFF	OFF	YES
Over-voltage B+ (Latched)	OFF	OFF	OFF	ON	OFF	OFF	YES
Overtemp (Latched)	OFF	OFF	OFF	OFF	ON	OFF	YES
Hall Error (Latched)	OFF	OFF	OFF	OFF	OFF	ON	YES

7.2.2 Under Voltage Fault:

When the +15VDC is below +12VDC, a level that would cause unreliable operation, the Run LED will turn off, a Fault Output is generated, and the amplifier is inhibited. This is not a latched condition: that is, if the problem is resolved the amplifier will resume operation.

The following is a list of possible causes:

1. Main AC line voltage is too low.
2. Bad rectifier bridge.
3. Bad DC buss filter capacitor.

7.2.3 Motor Over Temp Fault:

When the motor temperature has reached a level that, if exceeded, would damage the motor, the Run LED will turn off, the OVER TEMP LED will turn on and a Fault Output is generated, and the amplifier is inhibited. Note: This is a latched condition.

The following is a list of possible causes:

1. The continuous motor current is too high.
2. Binding or stalling of motor shaft due to excessive mechanical overload.
3. Motor rating too small for the load.

7.2.4 High Speed Electronic Circuit Breaker (HS/ECB) Fault:

When the peak output of the amplifier exceeds 80A for 10 micro-seconds, the Run LED will turn off, the HS/ECB LED will turn on and a Fault Output is generated, and the amplifier is inhibited. Note: This is a latched condition.

The following is a list of possible causes:

1. Shorted motor leads.
2. Motor inductance too low.
3. Short from a motor lead to ground.

7.2.5 Low Speed Electronic Circuit Breaker (LS/ECB) Fault:

When the RMS output of the amplifier exceeds 15/10A for standard 120/240VAC or 20/15A for High Power 120/240VAC for 3 seconds, the Run LED will turn off, the LS/ECB LED will turn on and a Fault Output is generated, and the amplifier is inhibited. Note: This is a latched condition.

The following is a list of possible causes:

1. Binding or stalling of motor shaft due to excessive mechanical overload.
2. Overload of amplifier output to motor.
3. Large reflected load inertia.

7.2.6 Over Temp Fault:

When the heatsink and or motor temperature has reached a level that, if exceeded, would damage the output transistors or the motor, the Run LED will turn off, the OVER TEMP LED is latched on, a Fault Output is generated, and the amplifier is inhibited.

The following is a list of possible causes:

1. Loss of cooling air - Fans are defective or airflow is blocked.
2. Excessive rise in cooling air temperature due to cabinet ports being blocked or excessive hot air being ingested.
3. Extended operational duty cycle due to mechanical overload of motor or defective motor.
4. The motors thermal switch has been tripped due to excessive overloading.

7.2.7 Over Voltage Fault:

When the DC-Buss voltage reaches a level that, if exceeded, would harm the amplifier or motor (i.e. +250VDC for standard and +450VDC for High Power), the Run LED will turn off, the Over-voltage LED=s are latched on, a Fault Output is generated, and the amplifier is inhibited.

The following is a list of possible causes:

1. Main AC line voltage is too high.
2. Decelerating a large inertial load. When decelerating, a DC motor acts as a generator. If the inertial load is large, the generated voltage can pump-up the DC-Buss. If this fault occurs, you may need a Regen Clamp. Consult Glentek.

7.2.8 Hall Error Fault:

When the amplifier fails to receive a hall sensor signal, the Run LED will turn off, the Hall Error LED is latched on, a Fault Output is generated, and the amplifier is inhibited.

The following is a list of possible causes:

1. Loss of +5 vdc to power Hall Sensor
2. Hall Sensor wire broken or intermittent connection to amp.
3. Hall 60/120 switch in wrong position.

7.2.9 Resetting A Fault:

The fault latch may be reset by pushing the Reset button, activating the Reset input J1-13 or by removing power and allowing the filter capacitor(s) to discharge. Note that the fault latch will not reset unless the fault has been cleared.

7.3 Amplifier Failure:

If an amplifier should fail, that is, if it should cease to operate with no apparent fault, the drawings in appendices A and B will enable a skilled technician to trouble-shoot an amplifier to even lower levels.

The modular construction of the amplifier allows fast and easy repair. This is especially true due to the plug-in

personality module card, since all user adjustments and configuration changes are made on this card. If an amplifier module should fail, simply unplug the pre-amp and plug it into a replacement amplifier.

The lowest-level parts or modules which Glentek recommends for field replacement are:

1. Fuses on the GP8600 power supply sub-assembly or the ones on the baseplate.
2. Fans 201-203
3. Amplifier modules A1-A6.

7.4 Factory Repair:

Should it become necessary to return an amplifier to Glentek for repair, please follow the procedure described below:

1. Reassemble the unit, if necessary, making certain that all the hardware is in place.
2. Tag the unit with the following information:
 - A. Serial number and model number.
 - B. Company name, phone number, and representative returning the unit.
 - C. A brief notation explaining the malfunction.
 - D. Date the unit is being returned.
3. Repackage the unit with the same care and fashion in which it was received. Label the container with the appropriate stickers (e.g: FRAGILE: HANDLE WITH CARE).
4. Contact a Glentek representative, confirm that the unit is being returned to the factory and obtain an RMA (Return Material Authorization) number. The RMA number must accompany the unit upon return to Glentek.
5. Return the unit by the best means possible. The method of freight chosen will directly affect the timeliness of its return.

Glentek also offers a 24-48 hr. repair service in the unlikely event that your system is down and you do not have a replacement amplifier module.

7.5 Warranty:

Any product, or part thereof, manufactured by Glentek, Inc., described in this manual, which, under normal operating conditions in the plant of the original purchaser thereof, proves defective in material or workmanship within one year from the date of shipment by us, as determined by an inspection by us, will be repaired or replaced free of charge, FOB our factory, El Segundo, California, U.S.A. provided that you promptly send to us notice of the defect and establish that the product has been properly installed, maintained, and operated within the limits of rated and normal usage, and that no factory sealed adjustments have been tampered with. Glentek's liability is limited to repair or replacement of defective parts.


Any product or part manufactured by others and merely installed by us, such as an electric motor, etc., is specifically not warranted by us and it is agreed that such product or part shall only carry the warranty, if any, supplied by the manufacturer of that part. It is also understood that you must look directly to such manufacturer for any defect, failure, claim or damage caused by such product or part.


Under no circumstances shall Glentek, Inc. or any of our affiliates have any liability whatsoever for claims or damages arising out of the loss of use of any product or part sold to you. Nor shall we have any liability to yourself or anyone for any indirect or consequential damages such as injuries to person and property caused directly or indirectly by the product or part sold to you, and you agree in accepting our product or part to save us harmless from any and all such claims or damages that may be initiated against us by third parties.


APPENDIX A


AMPLIFIER DRAWINGS












TOP BOARD




BOTTOM BOARD


8015-2000 Series

ITEM	GLENTEK PART NUMBER	MATERIAL DESCRIPTION		UNIT	QUANTITY
<div> <div> <p>THE INFORMATION CONTAINED IN THIS DOCUMENT WAS ORIGINATED BY GLENN RESEARCH CORPORATION, A DIVISION OF GLENN TECHNOLOGIES, INC. THIS INFORMATION IS NOT TO BE REPRODUCED, TRANSMITTED OR USED IN ANY MANNER WITHOUT PRIOR WRITTEN PERMISSION FROM ANTECH CORPORATION.</p> </div> <div> <p>UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES SURFACE FINISH: 320 SURFACE ROUGHNESS: .0005 TO .0015 DECIMALS PER INCH ANGULAR TOLERANCES: ± .5° ± .005 ± .005 FINISH: -</p> </div> </div>					
<div> <div> <p>LIST OF MATERIALS OR PARTS LIST</p> <p>SWA8715</p> <p>DATE</p> <p>C.J.</p> <p>NOV02</p> <p>CHECKED BY</p> <p>APPROVED BY</p> <p>C.V. R.V.</p> <p>POWER BOARD</p> <p>ASSEMBLY DRAWING</p> <p>SIZE</p> <p>CONSOLE NUMBER</p> <p>8715-2031-000</p> <p>SCALE 1:1</p> <p>FILE 8715-2031-000.FWG</p> <p>SHEET 1 OF 1</p> </div> <div> <p>GLENTEK</p> <p>El Segundo, CA 90234 USA</p> <p>910.322.3008 FAX 910.322.7789</p> <p>www.glenitek.com</p> <p>"Solutions for Medical Control"</p> </div> </div>					

NOTES: UNLESS OTHERWISE SPECIFIED







AMPLIFIER SYSTEM TOP VIEW

WIRING INFORMATION:

1. MAIN POWER: Refer to the 30A power supply sub-assembly drawing (drawing# 8600-2030) of the operation & service manual.
2. FAN POWER: TB201.
3. INDIVIDUAL AMPLIFIER: Refer to chapter 4 of the operation & service manual.

NOTES:

1. 120VAC OPERATION: 120VAC FANS, R201=10KOHM-10W, C201=6000MFD-250VDC AND GP8600-2030-120 POWER SUPPLY SUB-ASSEMBLY.
2. 240VAC OPERATION: 240VAC FANS, R201=20KOHM-10W, C201=3600MFD-450VDC AND GP8600-2030-240 POWER SUPPLY SUB-ASSEMBLY.
3. Use shielded cable for command signal.
4. Wiring to Amplifier A1 is typical for Amplifier A2.
5. Never ground the outputs of the amplifiers.

QTY	UNIT NO.	DESCRIPTION	UNIT OF MEASURE	ITEM
2	F8201 - 202	BUSSMANN FUSE BLOCK BM401350		10
1	1B201	WAGLION 2 PIN CONNECTOR		9
1	80001B28-	DOUBLE FUSE MOUNTING BRACKET		8
2	201 - 202	LIFELINE RUC 20A fuse - 150/60Hz		7
1	FAN201	FAN 120WAC @ 240VAC - 50/60Hz		6
1	80001B23-	REDUCED SIZE 2-AMPS BASEPLATE		5
1	CP86800-2030	PIN SUPPLY SUB-ASSEMBLY 30A		4
2	A1 - A2	SW8155 Amplifier Module		3
1	R201	Resistor, 10kOhm, 1W 20kOhm, 10W		2
1	CP201	Cap. 8000PF-250VDC/350VDC-450VDC		1

QTY	UNIT NO.	DESCRIPTION	UNIT OF MEASURE	ITEM
1	F8201 - 202	BUSSMANN FUSE BLOCK BM401350		10
1	1B201	WAGLION 2 PIN CONNECTOR		9
1	80001B28-	DOUBLE FUSE MOUNTING BRACKET		8
2	201 - 202	LIFELINE RUC 20A fuse - 150/60Hz		7
1	FAN201	FAN 120WAC @ 240VAC - 50/60Hz		6
1	80001B23-	REDUCED SIZE 2-AMPS BASEPLATE		5
1	CP86800-2030	PIN SUPPLY SUB-ASSEMBLY 30A		4
2	A1 - A2	SW8155 Amplifier Module		3
1	R201	Resistor, 10kOhm, 1W 20kOhm, 10W		2
1	CP201	Cap. 8000PF-250VDC/350VDC-450VDC		1

QTY	UNIT NO.	DESCRIPTION	UNIT OF MEASURE	ITEM
1	F8201 - 202	BUSSMANN FUSE BLOCK BM401350		10
1	1B201	WAGLION 2 PIN CONNECTOR		9
1	80001B28-	DOUBLE FUSE MOUNTING BRACKET		8
2	201 - 202	LIFELINE RUC 20A fuse - 150/60Hz		7
1	FAN201	FAN 120WAC @ 240VAC - 50/60Hz		6
1	80001B23-	REDUCED SIZE 2-AMPS BASEPLATE		5
1	CP86800-2030	PIN SUPPLY SUB-ASSEMBLY 30A		4
2	A1 - A2	SW8155 Amplifier Module		3
1	R201	Resistor, 10kOhm, 1W 20kOhm, 10W		2
1	CP201	Cap. 8000PF-250VDC/350VDC-450VDC		1


QTY	UNIT NO.	DESCRIPTION	UNIT OF MEASURE	ITEM
1	F8201 - 202	BUSSMANN FUSE BLOCK BM401350		10
1	1B201	WAGLION 2 PIN CONNECTOR		9
1	80001B28-	DOUBLE FUSE MOUNTING BRACKET		8
2	201 - 202	LIFELINE RUC 20A fuse - 150/60Hz		7
1	FAN201	FAN 120WAC @ 240VAC - 50/60Hz		6
1	80001B23-	REDUCED SIZE 2-AMPS BASEPLATE		5
1	CP86800-2030	PIN SUPPLY SUB-ASSEMBLY 30A		4
2	A1 - A2	SW8155 Amplifier Module		3
1	R201	Resistor, 10kOhm, 1W 20kOhm, 10W		2
1	CP201	Cap. 8000PF-250VDC/350VDC-450VDC		1

QTY	UNIT NO.	DESCRIPTION	UNIT OF MEASURE	ITEM
1	F8201 - 202	BUSSMANN FUSE BLOCK BM401350		10
1	1B201	WAGLION 2 PIN CONNECTOR		9
1	80001B28-	DOUBLE FUSE MOUNTING BRACKET		8
2	201 - 202	LIFELINE RUC 20A fuse - 150/60Hz		7
1	FAN201	FAN 120WAC @ 240VAC - 50/60Hz		6
1	80001B23-	REDUCED SIZE 2-AMPS BASEPLATE		5
1	CP86800-2030	PIN SUPPLY SUB-ASSEMBLY 30A		4
2	A1 - A2	SW8155 Amplifier Module		3
1	R201	Resistor, 10kOhm, 1W 20kOhm, 10W		2
1	CP201	Cap. 8000PF-250VDC/350VDC-450VDC		1

QTY	UNIT NO.	DESCRIPTION	UNIT OF MEASURE	ITEM
1	F8201 - 202	BUSSMANN FUSE BLOCK BM401350		10
1	1B201	WAGLION 2 PIN CONNECTOR		9
1	80001B28-	DOUBLE FUSE MOUNTING BRACKET		8
2	201 - 202	LIFELINE RUC 20A fuse - 150/60Hz		7
1	FAN201	FAN 120WAC @ 240VAC - 50/60Hz		6
1	80001B23-	REDUCED SIZE 2-AMPS BASEPLATE		5
1	CP86800-2030	PIN SUPPLY SUB-ASSEMBLY 30A		4
2	A1 - A2	SW8155 Amplifier Module		3
1	R201	Resistor, 10kOhm, 1W 20kOhm, 10W		2
1	CP201	Cap. 8000PF-250VDC/350VDC-450VDC		1

QTY	UNIT NO.	DESCRIPTION	UNIT OF MEASURE	ITEM
-----	----------	-------------	-----------------	------

NOTICE:
THE INFORMATION CONTAINED IN THIS DOCUMENT WAS OBTAINED BY AND IS THE EXCLUSIVE PROPERTY OF GLENITE, INC. THIS PROPRIETARY INFORMATION SHALL NOT BE REPRODUCED, TRANSMITTED TO OTHER DOCUMENTS, DISCLOSED TO FACTORIES, USED FOR MANUFACTURING OR ANY OTHER PURPOSE WITHOUT PRIOR WRITTEN PERMISSION FROM AN OFFICE OF GLENITE.



BASEPLATE SIDE VIEW

AMPLIFIER SYSTEM TOP VIEW

WIRING INFORMATION:


- 1. MAIN POWER: Refer to the 60A power supply sub-assembly drawing (drawing# 8600-2031) of the operation & service manual.
- 2. FAN POWER: TB201.
- 3. INDIVIDUAL AMPLIFIER: Refer to chapter 4 of the operation & service manual.


NOTES:


- 1. 120VAC OPERATION: 120VAC FANS, R201=10KOHM-10W, C201=6000MFD-250VDC AND GP8600-2031-120 POWER SUPPLY SUB-ASSEMBLY.
- 2. 240VAC OPERATION: 240VAC FANS, R201=20KOHM-10W, C201=3600MFD-450VDC AND GP8600-2031-240 POWER SUPPLY SUB-ASSEMBLY.
- 3. Use shielded cable for command signal.
- 4. Wiring to Amplifier A1 is typical for Amplifier A2, A3, A4.
- 5. Never ground the outputs of the amplifiers.

LIST OF MATERIALS OF PARTS LIST		ITEM
4	FB201-204	BUSSMANN FUSE BLOCK BM603150
1	TB201	MAXIMUM 2 PIN CONNECTOR
2	80001828-	DOUBLE FUSE MOUNTING BRACKET
4	F201-204	Littelfuse KIX 20A fuse or Limiton KIX 20A fuse
2	FAN201-202	FAN 120VAC or 240VAC - 50/60Hz
1	80001825-	REDUCED SIZE 4-AXIS BASEPLATE
1	GP8600-2031	PWR. SUPPLY SUB-ASSEMBLY 60A
4	A1 - A4	SMA8715 Amplifier Module
1	R201	Resistor 10Kohm 10W / 20Kohm 10W
2	C201	Cap. 6000MFD-250VDC/3600MFD-450VDC
1		4-AXIS BASEPLATE P/N: 80001825
UNLESS OTHERWISE SPECIFIED		GLENTEK INCORPORATED
REDUCED SIZE VERSION		REV. 1
SHEET 1 OF 1		SCALE N/A
SHEET 1 OF 1		DATE 8000-1835
SHEET 1 OF 1		REV. 1










NOTES:

- 120VAC OPERATION:
P/N OP8600-2030-120
Single 15ohm-95watt regen resistor(R301)
Regen Regulator(RC301) set to turn on at 225VDC
- 240VAC OPERATION:
P/N OP8600-2030-240
Two 15ohm-95watt regen resistors(R301, R302) in series
Regen Regulator(RC301) set to turn on at 400VDC

3. Unless otherwise specified all wires shall be UL approved.
4. For other configuration please consult with a Glenlex applications engineer.




NOTES:

1. 120VAC OPERATION:
P/N GP8600-2031-120
Single 15ohm-95watt regen resistor(R301)
Regen Regulator(RC301) set to turn on at 225VDC

2. 240VAC OPERATION:
P/N GP8600-2031-240
Two 15ohm-95watt regen resistors(R301, R302) in series
Regen Regulator(RC301) set to turn on at 400VDC


3. Unless otherwise specified all wires shall be UL approved.

4. For other configuration please consult with a Glentek applications engineer.





APPENDIX B


PERSONALITY MODULE














APPENDIX C

EUROPEAN UNION EMC DIRECTIVES

ELECTROMAGNETIC COMPATIBILITY GUIDELINES

FOR MACHINE DESIGN

This document provides background information about Electromagnetic Interference (EMI) and machine design guidelines for Electromagnetic Compatibility (EMC)

Introduction

Perhaps no other subject related to the installation of industrial electronic equipment is so misunderstood as electrical noise. The subject is complex and the theory easily fills a book. This section provides guidelines that can minimize noise problems.


The majority of installations do not exhibit noise problems. However, these filtering and shielding guidelines are provided as counter measures. The grounding guidelines provided below are simply good grounding practices. They should be followed in all installations.

Electrical noise has two characteristics: the generation or emission of electromagnetic interference (EMI), and response or immunity to EMI. The degree to which a device does not emit EMI, and is immune to EMI is called the device's Electromagnetic Compatibility (EMC).

Equipment, which is to be brought into the European Union legally, requires a specific level of EMC. Since this applies when the equipment is brought into use, it is of considerable importance that a drive system, as a component of a machine, be correctly installed.

"EMI Source-Victim Model" shows the commonly used EMI model. The model consists of an EMI source, a coupling mechanism and an EMI victim. A device such as servo drives and computers, which contain switching power supplies and microprocessors, are EMI sources. The mechanisms for the coupling of energy between the source and victim are conduction and radiation. Victim equipment can be any electromagnetic device that is adversely affected by the EMI coupled to it.

Figure 1 - EMI Source-Victim Model



Immunity to EMI is primarily determined by equipment design, but how you wire and ground the device is also critical to achieving EMI immunity. Therefore, it is important to select equipment that has been designed and tested for industrial environments. The EMI standards for industrial equipment include the EN61000-4-X series (IEC 1000-4-X and IEC801-X), EN55011 (CISPR11), ANSI C62 and C63 and MIL-STD-461. Also, in industrial environments, you should use encoders with differential driver outputs rather than single ended outputs, and digital inputs/outputs with electrical isolation, such as those provided with optocouplers.

The EMI model provides only three options for eliminating the EMC problem:

Reduce the EMI at the source.

Increase the victim's immunity to EMI (harden the victim).

Reduce or eliminate the coupling mechanism.

In the case of servo drives, reducing the EMI source requires slowing power semiconductor switching speeds. However, this adversely affects drive performance with respect to heat dissipation and speed/torque regulation.

Hardening the victim equipment may not be possible, or practical. The final and often the most realistic solution is to reduce the coupling mechanism between the source and victim. Filtering, shielding and grounding can achieve this.

Filtering

As mentioned above, high frequency energy can be coupled between circuits via radiation or conduction. The AC power wiring is one of the most important paths for both types of coupling mechanisms. The AC line can conduct noise into the drive from other devices, or it can conduct noise directly from the drive into other devices. It can also act as an antenna and transmit or receive radiated noise between the drive and other devices.

One method to improve the EMC characteristics of a drive is to use isolation AC power transformer to feed the amplifier its input power. This minimizes inrush currents on power-up and provides electrical isolation. In addition, it provides common mode filtering, although the effect is limited in frequency by the interwinding capacitance. Use of a Faraday shield between the windings can increase the common mode rejection bandwidth, (shield terminated to ground) or provide differential mode shielding (shield terminated to the winding). In some cases an AC line filter will not be required unless other sensitive circuits are powered off the same AC branch circuit.

NOTE: “Common mode” noise is present on all conductors that are referenced to ground. “Differential mode” noise is present on one conductor referenced to another conductor.

The use of properly matched AC line filters to reduce the conducted EMI emitting from the drive is essential in most cases. This allows nearby equipment to operate undisturbed. The basic operating principle is to minimize the high frequency power transfer through the filter. An effective filter achieves this by using capacitors and inductors to mismatch the source impedance (AC line) and the load impedance (drive) at high frequencies.

For drives brought into use in Europe, use of the correct filter is essential to meet emission requirements. Detailed information on filters is included in the manual and transformers should be used where specified in the manual.

AC Line Filter Selection

Selection of the proper filter is only the first step in reducing conducted emissions. Correct filter installation is crucial to achieving both EMI attenuation and to ensure safety. All of the following guidelines should be met for effective filter use.

The filter should be mounted to a grounded conductive surface.

The filter must be mounted close to the drive-input terminals, particularly with higher frequency emissions (5-30 MHz). If the distance exceeds 600mm (2 feet), a strap should be used to connect the drive and filter, rather than a wire.

The wires connecting the AC source to the filter should be shielded from, or at least separated from the wires (or strap) that connects the drive to the filter. If the connections are not segregated from each other, then the EMI on the drive side of the filter can couple over to the source side of the filter, thereby reducing, or eliminating the filter effectiveness. The coupling mechanism can be radiation, or stray capacitance between the wires. The best method of achieving this is to mount the filter where the AC power enters the enclosure. “AC Line Filter Installation” shows a good installation and a poor installation.





Figure 2- AC Line Filter Installation

When multiple power cables enter an enclosure, an unfiltered line can contaminate a filtered line external to the enclosure. Therefore, all lines must be filtered to be effective. The situation is similar to a leaky boat. All the holes must be plugged to prevent sinking

	<p style="text-align: center;">WARNING</p> <p>Large leakage currents exist in AC line filters. They must be grounded properly before applying power. Filter capacitors retain high voltages after power removal. Before handling the equipment, voltages should be measured to determine safe levels prior to handling the equipment. Failure to observe this precaution could result in severe bodily injury.</p>
---	---

If the filter is mounted excessively far from the drive, it may be necessary to mount it to a grounded conductive surface, such as the enclosure, to establish a high frequency (HF) connection to that surface. To achieve the HF ground, direct contact between the mounting surface and the filter must be achieved. This may require removal of paint or other insulating material from the cabinet or panel.

The only reasonable filtering at the drive output terminals is the use of inductance. Capacitors would slow the output switching and deteriorate the drive performance. A common mode choke can be used to reduce the HF voltage at the drive output. This will reduce emission coupling through the drive back to the AC line. However, the motor cable still carries a large HF voltage and current. Therefore, it is very important to segregate the motor cable from the AC power cable. More information on cable shielding and segregation is contained in the section on shielding.

Grounding

High frequency (HF) grounding is different from safety grounding. A long wire is sufficient for a safety ground, but is completely ineffective as a HF ground due to the wire inductance. As a rule of thumb, a wire has an inductance of 8 nH/in regardless of diameter. At low frequencies it acts as constant impedance, at intermediate frequencies as an inductor, and at high frequencies as an antenna. The use of ground straps is a better alternative to wires. However the length to width ratio must be 5:1, or better yet 3:1, to remain a good high frequency connection.

The ground system's primary purpose is to function as a return current path. It is commonly thought of as an equipotential circuit reference point, but different locations in a ground system may be at different potentials. This is due to the return current flowing through the ground systems finite impedance. In a sense, ground systems are the sewer systems of electronics and as such are sometimes neglected.

The primary objective of a high frequency ground system is to provide a well-defined path for HF currents and to minimize the loop area of the HF current paths. It is also important to separate HF grounds from sensitive circuit grounds. "Single Point Ground Types" shows single point grounds for both series (daisy chain) and parallel (separate) connections. A single point, parallel connected ground system is recommended.



Figure 3-Single Point Ground Types

A ground bus bar or plane should be used as the "single point" where circuits are grounded. This will minimize common (ground) impedance noise coupling. The ground bus bar (GBB) should be connected to the AC ground, and if necessary, to the enclosure. All circuits or subsystems should be connected to the GBB by separate connections. These connections should be as short as possible and straps should be used when possible. The motor ground conductor must return to the ground terminal on the drive, not the GBB.

Shielding and Segregation

The EMI radiating from the drive enclosure drops off very quickly over distance. Mounting the drive in an enclosure, such as an industrial cabinet, further reduces the radiated emissions. The cabinet should have a high frequency ground and the size of the openings should be minimized. In addition, the drive is considered an "open" device that does not provide the proper IP rating for the environment in which it is installed. For this reason the enclosure must provide the necessary degree of protection. An IP rating or Nema rating (which is similar to IP) specifies the degree of protection that an enclosure provides.

The primary propagation route for EMI emissions from a drive is through cabling. The cables conduct the EMI to other devices, and can also radiate the EMI. For this reason, cable segregation and shielding are important factors in reducing emissions. Cable shielding can also increase the level of immunity for a drive. For example:

- Shield termination at both ends is extremely important. The common misconception that shields should be terminated at only one end originates from audio applications with frequencies <20 kHz. RF applications must be terminated with the shield at both ends, and possibly at intermediate points for exceptionally long cables.
- When shielded cables are not terminated at the cable connection and pass through the wall of a cabinet, the shield must be bonded to the cabinet wall to prevent noise acquired inside the cabinet from radiating outside the cabinet, and vice versa.
- When shielded cables are terminated to connectors, the shield must be able to provide complete 360° coverage and terminate through the connector backshell. The shield must not be grounded inside the connector through a drain wire. Grounding the shield inside the connector couples the noise on the shield to the signal conductors sharing the connector and virtually guarantees failure to meet European EMC requirements.
- The shield must be continuous. Each intermediate connector must continue the shield connection through the backshell.
- All cables, both power and signal should use twisted wire pairing.

The shield termination described above provides a coaxial type of configuration, which provides magnetic shielding, and the shield provides a return path for HF currents that are capacitively coupled from the motor windings to the frame. If power frequency circulating currents are an issue, a 250 VAC capacitor should be used at one of the connections to block 50/60 Hz current while passing HF currents. Use of a properly shielded motor cable is essential to meet European EMC requirements.

The following suggestions are recommended for all installations.

1. Motor cables must have a continuous shield and be terminated at both ends. The shield must connect to the ground bus bar or drive chassis at the drive end, and the motor frame at the motor end. Use of a properly shielded motor cable is essential to meet European EMC requirements.
2. Signal cables (encoder, serial, and analog) should be routed away from the motor cable and power wiring. Separate steel conduit can be used to provide shielding between the signal and power wiring. Do not route signal and power wiring through common junctions or raceways.
3. Signal cables from other circuits should not pass within 300 mm (1 ft.) of the drive.
4. The length or parallel runs between other circuit cables and the motor or power cable should be minimized. A rule of thumb is 300 mm (1 ft.) of separation for each 10 m (30 ft.) of parallel run. The 300 mm (1 ft.) separation can be reduced if the parallel run is less than 1 m (3 ft.).
5. Cable intersections should always occur at right angles to minimize magnetic coupling.
6. The encoder mounted on the brushless servomotor should be connected to the amplifier with a cable using multiple twisted wire pairs and an overall cable shield. Encoder cables are offered in various lengths that have correct terminations.

Persistent EMI problems may require additional countermeasures. The following suggestions for system modification may be attempted.

1. A ferrite toroid or "doughnut" around a signal cable may attenuate common mode noise, particularly RS-232 communication problems. However, a ferrite toroid will not help differential mode noise. Differential mode noise requires twisted wire pairs.
2. Suppress each switched inductive device near the servo amplifier. Switch inductive devices include solenoids, relay coils, starter coils and AC motors (such as motor driven mechanical timers).
3. DC coils should be suppressed with a "free-wheeling" diode connected across the coil.
4. AC coils should be suppressed with RC filters (a 200 Ohm 1/2 Watt resistor in series with a 0.5 uF, 600 Volt capacitor is common).

Following these guidelines can minimize noise problems. However, equipment EMC performance must meet regulatory requirements in various parts of the world, specifically the European Union. Ultimately, it is the responsibility of the machine builder to ensure that the machine meets the appropriate requirements as installed.

RECOMMENDATIONS FOR GLENTEK AMPLIFIERS

All amplifiers installed in a NEMA 12 enclosures or equivalent with wiring in metal conduit or enclosed metal wire trough (see Shielding and segregation).

Use Glentek shielded feedback and motor cables.

An AC line filter properly installed in a NEMA 12 enclosure or equivalent (see Filtering).

AC line filters for single-phase applications

1A-15A input current, 120-250VAC use: Corcom 15ET1 or equivalent.

15A-25A input current, 120-250VAC use: Corcom 25FC10 or equivalent.

25A-36A input current, 120-250VAC use: Corcom 36FC10 or equivalent.

AC line filters for 3-phase applications

1A-25A input current, 120-250VAC use: Corcom 25FCD10 or equivalent.

25A-36A input current, 120-250VAC use: Corcom 36FCD10 or equivalent.

36A-50A input current, 120-250VAC use: Corcom 50FCD10 or equivalent.

50A-80A input current, 120-250VAC use: Corcom 80FCD10 or equivalent.



**EUROPEAN UNION
DECLARATION OF INCORPORATION
MOTION CONTROL SYSTEMS**
Classified as Components of Machinery
Model Series SMA8715

**Council Directive****89/392/EEC****Machinery Directive**

The Products cited below and their accessories comply with the following Safety of Machinery Standards when installed and operated in accordance with the Instructions provided in the Operation & Installation Manuals. The products are declared to comply by virtue of Design Third Party Evaluations and Testing. EMC Testing and Product Safety Evaluations and Risk Assessments were conducted by NATIONAL TECHNICAL SYSTEMS, an independent Nationally Recognized Test Laboratory, located in Fullerton, CA 92631, USA.

As components of Machinery, please be advised that:

1. These are not individually classified as machinery within the scope of directive 89/392/EEC.
2. These are intended to be incorporated into machinery or to be assembled with other machinery to constitute machinery covered by directive 89/392/EEC, as amended.
3. As such, do therefore not in every respect comply with the provisions of directive 89/392/EEC.

SAFETY STANDARDS

EN60292 - 2	Safety of Machinery – Basic Principals	
EN60204	Electrical Equipment of Industrial Machines	
	Collateral Test Standards, Specified by EN60204	
EN50011:1991	Emissions Limits for Industrial, Scientific	Class A
	And Medical (ISM) RF Equipment	Conducted and Radiated
EN61000-4-2	Electrostatic Discharge Immunity	Level 2
EN61000-4-3	Radiated Emission Immunity	Level 2
EN61000-4-4	Electric Fast Transients Burst	Level 3

Manufacturers Name: GLENTEK INC.
 Manufacturers Address: 208 Standard Street, El Segundo, CA 90245, USA
 Description of Equipment: Motion Control Systems including Amplifiers and Servo Motors
 Model Number(s): SMA8715, SMA8715HP.
 The above amplifier modules packaged in the following configurations: -1, -1A-1, -2A-1, -2A-2, -4A-3, -4A-4, -6A-5, -6A-6, -3U-1 and all power supply configurations: 00, 01, 02, 03.

The undersigned hereby declares that the equipment specified above conforms to the noted Directives and Standards in accordance with "The Machinery Directives". Refer to Technical Construction File GTK 99408.

MANUFACTURER

Helen M. Vasak

HELEN M. VASAK
SECRETARY-TREASURER

4-19-99

Prepared By: National Technical Systems, Fullerton, CA
 Confirmed By: Chuck Helton, Director of Product Safety

NOTES

NOTES

Omega Series Digital PWM Brushless Servo Amplifiers

- PWM (Pulse-Width-Modulated) Brushless servo amplifiers to 20KW

Analog Brush Type Servo Amplifiers

- Linear Brush type servo amplifiers to 2.6KW
- PWM (Pulse-Width-Modulated) Brush type servo amplifiers to 28KW

Analog Brushless Servo Amplifiers

- Linear Brushless servo amplifiers to 3.5KW
- PWM (Pulse-Width-Modulated) Brushless servo amplifiers to 51KW

Permanent Magnet DC Brush Type Servo Motors

- Continuous Torques to 335 in. lb.
- Peak Torques to 2100 in. lb.

Permanent Magnet DC Brushless Servo Motors

- Continuous Torques to 1100 in. lb.
- Peak Torques to 2200 in. lb.



MANUAL#: 8715-1040-000
REVISION: (C)
DATE: 29 October 2002

208 Standard Street, El Segundo, California 90245, USA.
Telephone: (310) 322-3026; Fax: (310) 322-7709
www.glentek.com e-mail: sales@glentek.com

